



Condition Based Monitoring Program Setup Guide

Version 0.2 – 3-axis

Created:	11/01/2019
Author:	Sharkey, Tom
Last Modified:	13/01/2021
Modified by:	Sharkey, Tom

1 Contents

1 Contents	2
2 Overview	3
3 Components	5
3.1 Hardware Kit	5
3.2 Software Requirements	5
4 Setup	6
4.1 Executable Setup	6
4.2 Python Setup	7
4.2.1 Python 2.7	7
4.2.2 Pip Installations	8
4.2.3 CbM installation	12
5 Hardware Setup	13
6 Getting Started	18
6.1 GUI	19
6.1.1 Motes	19
6.1.2 Mode	20
6.1.3 Action	22
6.1.4 Alarm setting	23
6.1.5 Reset	25
6.1.6 Settings	26
6.1.7 Help	30
6.2 Command Window	32
7 Support	33
7.1 Installing updates	33
7.1.1 Crosscore	33
7.1.2 Hex File	34
7.1.3 Installing and resetting the mote	35
7.1.4 Putting it all together	38
7.2 Troubleshooting	42

2 Overview

This document will give a high-level explanation of the function and setup of Analog Devices' Condition Based Monitoring (CBM) evaluation software and hardware. This includes a brief introduction to the software and how it is used with the CBM hardware. It also includes a step-by-step guide on the functionality of the CBM Graphical User Interface (GUI).

The function of the system is to provide an evaluation tool for a wireless signal chain for MEMS accelerometer based vibration monitoring. The hardware can be directly attached to a motor or fixture, either magnetically or via a stud.




Figure 1: SmartMesh layout

The CBM hardware signal chain consists of a tri-axis ADXL356 accelerometer mounted to the base of the module. The output of the ADXL356 is read into the AD7685 ADC, and then processed by the ADuCM4050 low power microcontroller. Here it is buffered, transformed to the frequency domain and streamed to the SmartMesh IP mote. From the SmartMesh chip it is wirelessly streamed to the SmartMesh IP Manager. The manager connects to a PC and visualization and saving of the data can take place.




Figure 2: 3-axis mote breakdown

3 Components

3.1 *Hardware Kit*

- SmartMesh IP Manager (DC2274A)
- EV-CBM-VOYAGER3-2Z Hardware Module (referred to as “Mote”)
- JTAG Cable (only needed for firmware upgrade)



Figure 3: Hardware Required

3.2 *Software Requirements*

For Python Install:

- Python 2.7.15
- Pip for Python
- Matplotlib
- PySerial
- Scipy
- Pandas
- openpyxl
- CBM_app (provided)

For Exe Install (Windows Only):

- CBM_app.exe

4 Setup

4.1 Executable Setup

This setup is suitable for Windows users only and is not guaranteed to work for every machine. It requires little installation as an executable has been created to do this work for you.

- Open the folder which contains CBM_app.exe.
- Double click on the .exe.




Figure 4: Run Executable


The program launches for you automatically. It can be a little slow to launch (up to 1 minute), particularly the first time it is done. If the program does not launch, the executable may not be suited to your machine. The python setup may be used instead.

4.2 Python Setup

PLEASE NOTE: If the executable setup 4.1 has succeeded for you, these steps are not necessary.

4.2.1 Python 2.7

- Navigate to the downloads page of python.org, <https://www.python.org/downloads/release/python-2715/>
- Download the appropriate version of python i.e. 2.7.15: Windows, Linux
- If you wish to use a version of Python that is not 2.7, consult the [Troubleshooting](#) section of this guide. Be aware, the code has not been tested outside of Python v2.7.
- Python IDLE was the environment used to write this program, and should function correctly if all these steps are followed correctly. The same procedure does not guarantee success for other Python Environments (such as PyCharm).




Version	Operating System	Description	MD5 Sum
Gzipped source tarball	Source release		045fb344
XZ compressed source tarball	Source release		a80ae3cc
macOS 64-bit/32-bit installer	Mac OS X	for Mac OS X 10.6 and later	9ac8c85d
macOS 64-bit installer	Mac OS X	for OS X 10.9 and later	223b713d
Windows debug information files	Windows		4c61ef61
Windows debug information files for 64-bit binaries	Windows		680bf74b
Windows help file	Windows		2973154d
Windows x86-64 MSI installer	Windows	for AMD64/EM64T/x64	0ffa44a8
Windows x86 MSI installer	Windows		023e49c5

- Run Python's installation setup, installing it for **a single user only**.




- Check for installation by searching python in search bar, checking if IDLE appears.



4.2.2 Pip Installations


- Pip is installed for you in the folder C:/Python27/Scripts (if you have installed and saved Python correctly).
- To use pip you must navigate to this folder as follows:
- Navigate to C:/ by hitting the windows key, then clicking “computer”.




- Double click **DRIVE_C (C:/)**.




- Double click **python27**.




- Double click **Scripts**.



- Then on any white space in the window, press shift and right click, as shown below.
- Now click “open command window here”. This opens the cmd in this directory.



- The command window should now say `C:/Python27/Scripts>` , which indicates that you are in the correct folder.




- The basic command for each module installed will be

pip install < filename >

The modules to be installed for the version of this software indicated on the cover of this document are:

- Pyserial (v2.7)
- Matplotlib (v2.2.3)
- scipy (v1.2.2)
- pandas (v0.23.3)
- openpyxl (v2.6.4)


Please note, the version numbers included are simply the ones used in the tested setup. The most recent versions should suffice and will be installed if the pip install command is used.



```
C:\Python27\Scripts>pip install pyserial==2.7; matplotlib==2.2.3; scipy==1.2.2; pandas==0.23.3; openpyxl==2.6.4
```

Note, the module names are divided by a semicolon (;)


Alternatively, each of these modules can be installed individually.



```
C:\Python27\Scripts>pip install matplotlib==2.2.3
```

4.2.3 CbM installation

- Open the folder containing this word doc, open the folders app->Simple, and then double click on the app shown called “CBM_app”.
- This may ask you to choose a program. Simply right click the file instead -> open with -> and choose python from the pop up list.



- The screen below pops up. This is the graphical interface for the program. Leave this open for the next set of steps.




Figure 5: Completed GUI setup

5 Hardware Setup

- Connect the wireless manager to any USB port on your computer.
- As this is a new device, the drivers for it may take a few minutes to install. It is important that this step happens before the mote is powered up.
- If you have purchased your own manager, there are additional steps which are outlined in [Troubleshooting](#).



Figure 6: Inserting manager into USB port

- Power up the mote by inserting the provided batteries.
- **CAUTION: Note the polarity of the batteries in the mote.** The positive + end should be attached to the side with the **RED** wire.
- The negative – end should be attached to the side with the **BLACK** wire. Failure to do so could result in device damage.




Figure 7: Mote with Batteries, uncovered

- Put batteries in the wireless mote and **wait** for the steady green light to begin **flashing**. This is the network establishing automatically.
- Be patient, this takes on average: **2-3 minutes** to complete.



Figure 8: Mote with Cover

- Use your search bar to open **device manager** on the computer and scroll down to **Ports (COM & LPT)**.




Figure 9: Device Manager

- Click the arrow. There should be 4 COM ports in sequential order as shown above i.e. COM16, COM17, COM18, and COM19.
- If these ports do not appear a few minutes after you have plugged the manager in, please consult the guide on [analog.com](http://www.analog.com/media/en/technicaldocumentation/user-guides/smartmesh_ip_tools_guide.pdf) http://www.analog.com/media/en/technicaldocumentation/user-guides/smartmesh_ip_tools_guide.pdf, Section 3.2 for troubleshooting driver installation for the FTDI drivers.
- Choose **the last of these four** COM ports. e.g. COM19.
- Enter this number in your new program as shown and click connect.




Figure 10: Enter 4th COM

- The graph of the mote appears on screen, as well as some connection information.



Figure 11: Mote time series output

- To calibrate the device, place it somewhere steady, with little movement, and click “remove ADC offset”.



Figure 12: Removing ADC offset

- If you have trouble connecting to the mote, take the battery out and put it back in again. You can also try closing and opening ‘CBM_app’ again.
- You have completed the installation of this program and its associated modules.
- Please note, when connecting the manager and mote in future, it is preferable to **plug in the manager before powering the mote**.

6 Getting Started

With your mote and manager connected, and the CBM_app software running, there are several functions available to you.

The software opens, displaying a plot of the acceleration of the motes against time in addition to a graph which plots the Discrete Fourier Transform (DFT) of the time series plots.

Please note that the software is intended for vibration measurements in industrial machinery and as such, requires some level of g force to indicate any meaningful change on the graphs. To check operation manually, shake the mote for 4 to 5 seconds to show changes on the graph.



Figure 13: Axis of ADC acceleration

6.1 GUI

The graphical user interface, or GUI, refers to the main window upon which the plots and options are being displayed. The GUI can currently display the information of multiple motes, but the user may experience program slowness with more than 3 motes connected.

6.1.1 Motes

In the upper right corner, a number of green LEDs displays the number of connected motes.

The GUI displays mote plots in the form of a “Notebook”. This means that clicking on the “Mote #2” tab will update the GUI to display the plots from that mote. Currently a tab will not start plotting mote data until the user first switches to that tab.



Figure 14: Switch Mote Plots

6.1.2 Mode

First, observe in the top left corner of the window, a dropdown button labelled “Mode”. This button, when clicked, lists a number of options for plots which can be displayed in place of the DFT. Selecting “peak” for example, will display the largest measured acceleration of the mote(s) over time. You are encouraged to explore the other modes, which all analyse the data from the time series plot in a different way.




Figure 15: Changing the mode

Mode	Explanation
DFT	Discrete Fourier Transform. Conversion of time domain data to the frequency domain. Gives clearer representation of source of vibration acting on the mote. Rotation of motor seen at lower frequencies, bearing faults seen at higher frequencies.
Peak	Measures the max value achieved for each plot of time domain data (512 values), and plots this value on graph.
Peak-to-Peak	Similar to peak, measures difference between max and min value achieved by time domain data (512 values), and plots this value on graph. Typical value is twice that of “peak” value.
Mean	Calculates the root mean square (rms) value of the time series data (512 bits). This is the average value of the time domain data if all values are made positive.
Standard Deviation	Measures of the average distance of a time series data point from the mean.
Kurtosis	Kurtosis indicates whether outliers are infrequent and extreme (high kurtosis), or frequent and moderately sized (low kurtosis). The kurtosis value plotted is “Excess kurtosis”, for which the normal distribution has a value of 0. Deviations from a zero value for kurtosis can be used to indicate a bearing fault.
Skew Factor	Indicates the “slant” of the signal when sorted into a probability density function. A negative skew indicates a long “tail” to the left of the function.
Crest Factor	Indicates how extreme the peaks are in a waveform. The greater the crest factor, the greater the energy contained in higher frequency harmonics. Higher frequency harmonics are often used to mark bearing issues

Table 1: Statistical Functions

For a more in-depth explanation of these functions and their use in the program, please consult the companion document included, “Condition Based Monitoring Statistical Functions”.

6.1.3 Action

Next, there is the “Action” dropdown. This allows you to open a menu, and select a number of data sets to be saved to an SQL database. The program saves time and DFT data, as well as each of the “mode” values. This data is saved to an SQL file named “motedata.db” which is created in the same directory as the program is running.

After saving has been completed, this SQL database can be converted to an excel file using the “Convert to Excel” button. Depending on the size of the SQL file this may take some time. The information in the SQL file (saved as DB file) can be viewed only using a database browser, available online: <https://sqlitebrowser.org/dl/>. Simply download the program that suits your operating system anywhere on your computer. Then navigate to the “motedata.db” file > right click > Open with > DB Browser.

Please note, if the program saves data on many different occasions, it always saves to the same database file “motedata.db”. This file must be deleted manually if you wish to start saving to an empty database.

NOTE: Hit “Enter” to save the data to the SQL database before converting to excel.




Figure 16: Save Data

```
[275871864] Got complete frame @ 180.865902167
.....SAVING DATA.....
[272539976] Got complete frame @ 183.954573878
.....SAVING DATA.....
[275871864] Got complete frame @ 185.096782092
.....SAVING DATA.....
[272539976] Got complete frame @ 188.754087262
.....SAVING DATA.....
```

Figure 17: GUI confirmation of saving

6.1.4 Alarm setting

Under Action > Set Alarm, there is a pop up menu which allows the user to set limits on a single value that a mote should reach. This means for example that a mote should not exceed 1g acceleration peak value. If this value is exceeded, a red LED on the mote lights, and the GUI indicates that an alarm has been triggered. This does not affect mote transmission, the mote continues to transmit as normal after the alarm has been triggered.

The reset button is used to reset the LED on the mote to a blinking green.



Figure 18: Setting Alarms




Figure 19: Mote with alarm triggered

6.1.5 Reset

“Reset” is a dropdown that offers you the option to clear all previously recorded data in the mode plots, such as “peak”, “mean”, “kurtosis”, etc. This clears the plots, which will again gradually fill as data from the motes is received.

This function is useful in allowing you to remove the results recorded which contain the “ADC offset voltage” i.e. before you have clicked and unclicked the “Remove ADC offset” button.



Figure 20: Resetting Graphs

6.1.6 Settings

The “Settings” dropdown opens a menu through which you can set a number of important parameters for the incoming mote data.

Please note, changing these settings alters the configuration of the ADC. Therefore, you must **remove the offset again** after changing these settings.

Sampling:

The **sampling frequency** setting changes the number of data points collected per second. A higher sampling frequency will result in a smaller time-window being displayed, for example:

- 1s for 510Hz
- 0.5s for 1000Hz

For higher sampling frequencies, higher frequency information will be shown on the DFT axis.




Figure 21: Sampling parameters

DFT Axis:

DFT axis allows the user to **set the boundaries for the DFT plot**. This allows the user to focus in on a particular set of values.

The user manually sets the values for

X-Axis start and end

Y-Axis start and end

If auto is selected, the plot will automatically scale to the data.

Take special care to choose values small enough to see the data.




Figure 22: DFT axis

Motor markers

This option allows the user to enter default values for a motor to plot where spikes in frequency are expected to occur, for a motor at a specified RPM. This places markers on the DFT plot that can be compared to real data for a motor.



Figure 23: Motor Speed Markers

Bearing markers

This option allows user to fill in some information on the bearing characteristics of the vibration source being measured, which are used to calculate the expected frequencies of inner and outer bearing defects. These are marked on the DFT plot to indicate the frequencies bearing faults would occur at if present.



Figure 24: Bearing Fault Markers

Axes Received

This list of options allows the user to select which accelerometer axis information is sent by the mote. Any combination of axes can be sent together. This allows for faster sending of individual axes, if the user is not interested in seeing X, Y and Z data for the mote.




Figure 25: Axes Received

6.1.7 Help

“Help” is a dropdown which provides a small amount of information on the functionality of the software. It also provides detailed information about the network of the manager and motes. Click “Network Info” to get information about the network, or “CBM Help” to get information about the program.




Figure 26: Help Options




Figure 27: Network Info Popup





Figure 28: Help Popup

6.2 Command Window

When the program is launched, the CBM Graphical User Interface (GUI) is launched, alongside a blank window, which may be different in colour depending on how the program was started. This is the command window.


Upon connecting, the command window displays some connected messages, in addition to the mac addresses of the connected motes.

During the runtime of the program, the command window displays further information about when and which packets are being received by the manager.

A screenshot of a Windows command window titled "C:\Users\tsharkey\Desktop\v03_For_Richard\CBM_app_v03.exe". The window has a black background with white text. The text shows the program's startup sequence: "Connected and subscribed to data notifications", "- retrieve the list of all connected motes", "Found the following operational motes:", "- 00-17-0d-00-00-31-c4-4c", followed by five "Waiting for start of new frame" messages and one "Got complete frame @ 1.09967248088e-06" message. Then it says "Successfully Sent" and shows three more "Got complete frame" messages with timestamps: "2.98771079347", "6.40924091441", and "10.2951550263".

```
C:\Users\tsharkey\Desktop\v03_For_Richard\CBM_app_v03.exe
Connected and subscribed to data notifications
- retrieve the list of all connected motes
Found the following operational motes:
- 00-17-0d-00-00-31-c4-4c
[220528192] Waiting for start of new frame
[220528192] Waiting for start of new frame
[220528192] Waiting for start of new frame
[220528192] Waiting for start of new frame
[220528192] Waiting for start of new frame
[220528192] Got complete frame @ 1.09967248088e-06
Successfully Sent
[220528192] Got complete frame @ 2.98771079347
[220528192] Got complete frame @ 6.40924091441
[220528192] Got complete frame @ 10.2951550263
```

Figure 29: Command window during program operation

A screenshot of a command window showing a continuous stream of "Got complete frame" messages. Each message is preceded by a timestamp in brackets. The timestamps are: [206163640], [240628040], [206163640], [206163640], [206163640], [206163640], [206163640], [240628040], [206163640], [240628040], [206163640], [240628040], [206163640], [206163640], [206163640], [240628040]. The corresponding timestamps for "Got complete frame" are: 7.33083278627e-07, 1.67538119414, 4.27803209659, 8.60655970249, 9.04775084552, 13.2745972349, 16.6452137176, 19.1691325755, 23.562285871, and 25.2437718161.

```
[206163640] Waiting for start of new frame
[240628040] Waiting for start of new frame
[206163640] Waiting for start of new frame
[206163640] Waiting for start of new frame
[206163640] Waiting for start of new frame
[206163640] Got complete frame @ 7.33083278627e-07
[240628040] Got complete frame @ 1.67538119414
[206163640] Got complete frame @ 4.27803209659
[206163640] Got complete frame @ 8.60655970249
[240628040] Got complete frame @ 9.04775084552
[206163640] Got complete frame @ 13.2745972349
[240628040] Got complete frame @ 16.6452137176
[206163640] Got complete frame @ 19.1691325755
[206163640] Got complete frame @ 23.562285871
[240628040] Got complete frame @ 25.2437718161
```

Figure 30: Program when frames are correctly received


7 Support

7.1 *Installing updates*


The notes that have been sent to you are capable of being updated via software (hex files), that will be sent to you from Analog Devices. There are a number of steps that must be taken in order to ensure these updates are installed correctly, outlined below.


7.1.1 Crosscore

Crosscore is an Analog Devices program that can be used to flash to a device if the user has a hex file. It can be downloaded for free [here](#) (or look up Analog Devices Crosscore Utilities).



Next, hit run and follow the instructions for installing the software.





7.1.2 Hex File

- A hex file will be included in the installed package, in the folder “Hex Files”
- It must be saved to your computer somewhere you will be able to find it.

 cbm512.hex	10/11/2018 2:39 PM	HEX File	319 K
--	--------------------	----------	-------

7.1.3 Installing and resetting the mote

- It is useful for this section to have two pens or other narrow implements that can be used to press two small buttons on the programming board.
- In order to program the microcontroller board, it must first be released from its vertical position on the mote. This is accomplished by sliding the board up and gently pulling it away from the casing.



Figure 31: Release board



Figure 32: Board Removed

- To put the mote in “Flash” mode, the programming board must be attached to the microcontroller board and secured with a clamp.




Figure 33: Board clamped to programming board

- Ensure the boards are securely connected and power is supplied to the microcontroller board.
- Now the two golden buttons on the programming board, SW1 and SW2, must be pressed in a specific fashion to enter “Flash” mode.
- SW1 must be held down while SW2 is **pressed and released**.
- SW1 can then also be released.
- This sequence is equivalent to holding down an option for “Flash” mode while the system is being reset.




Figure 34: Mote Flash Preparation – Programming Board




Figure 35: Complete JLINK connection

- Make sure the USB end of the JLINK cable is plugged in to your computer.



Figure 36: JLINK - USB to computer

7.1.4 Putting it all together

Search for and open the crosscore program on your computer. A screen like what is shown below should open. Some options may be selected for you, but for the sake of clarity, we will go through each step.




Figure 37: CrossCore setup

- For the “Target” selection box, select the ADuCM4x50.
- Connect the JLINK cable to your mote as shown and the USB to the USB port of your computer.
- You should now be able to select the JLINK port in the “Serial Port” menu of the crosscore program.
- For “Baudrate”, select 115200.
- For “Action” select Program.
- Leave “Key” blank.
- The “Second stage kernel” section should be automatically filled in.

- For “File to download”, browse for and select the hex file you have downloaded, wherever it may be on your computer.
- The program is now ready to be loaded onto your mote.
- Click “Start” in the bottom right corner. You should see some loading and a load complete message as shown. You can now close this window.




Figure 38: Completed CrossCore

- Please note, the mote must now be RESET. This is done by pressing the SW2 button as indicated in Fig.34.
- The green light should blink to life.



Figure 39: Mote after reset

- You have now successfully updated the mote.

7.2 **Troubleshooting**

Note:

(1)

The CBM application does not currently run with Serial Mux installed on your computer. If serial mux is installed on your computer, it must be suspended or removed in order for CBM to run. Further info can be found in the [SmartMesh IP Tools Guide](#). This guide also mentions Stargazer, an application to view the network topology. This is not needed for the CBM_app but provides a visual demonstration of the network.

(2)

Many changes in the app do not occur instantly. If the executable setup is used, the user should expect to wait a while in order for the program to gather all of the libraries it depends on. During this time, the program will appear as a blank command prompt.

Q: I have completed setup but the mote's light is not blinking.

A: This problem indicates that the network between the mote and manager has not been established. The network between these two pieces of hardware forms automatically. **Connecting the manager before the mote** should help ensure this network forms correctly.

Alternatively, this may be an issue with the network ID's of the manager and mote. You may refer to another troubleshooting question: “Q: *I have purchased my own manager. Why can't I connect?* “. This will guide you in resetting the network ID of your manager to match that of your mote.

Q: The application is running, but the data does not appear to change when I move the mote.

A: Try shaking vigorously and ensure that the mote is being shaken in the direction of an accelerometer axis, X, Y or Z for best results.



Figure 40: Axis of acceleration

Q: My computer cannot find pip to install python modules.

A: Python versions below 2.7.9 do not install the pip package manager by default. If you have navigated correctly to the folder Python27 > Scripts, opened the command window in that folder, and pip is not a recognised command, python should be reinstalled. Ensure the version you download is 2.7.15. After you have completed installation, repeat the steps marked in **Pip Installations**. If this problem persists, consult the documents on installing pip [here](#).

Q: How can I save data to an Excel file without saving to a SQL database first?

A: In the current version of the code this feature does not exist. If you attempt to “Convert to Excel” without first saving to SQL by pressing “Enter”, an error will occur. This is because it is more efficient in terms of memory and performance to first save to SQL and convert to excel afterwards.


Q: I am getting a version mismatch error.

A: The Python program and the firmware for each mote have an agreed version to ensure that new code is not used with old firmware. If the GUI displays a version mismatch error, either the GUI or the firmware being used is outdated. It is best to update the Python GUI and the firmware being used to the newest version.

Q: I have purchased my own manager. Why can't I connect?

A: The mote that has been shipped to you has been set to a network ID which cannot be changed. In order for the mote and manager to communicate, the network ID of the manager must be changed. The steps to do this are outlined below:

- Download [TeraTerm](#) or [puTTY](#) if they are not already installed on your computer.



Download PuTTY: latest release (0.70)

[Home](#) | [FAQ](#) | [Feedback](#) | [Licence](#) | [Updates](#) | [Mirrors](#) | [Keys](#) | [Links](#) | [Team](#)
Download: [Stable](#) | [Snapshot](#) | [Docs](#) | [Changes](#) | [Wishlist](#)

ge contains download links for the latest released version of PuTTY. Currently this is 0.70 7-08.

ew releases come out, this page will update to contain the latest, so this is a good page to natively, here is a [permanent link to the 0.70 release](#).

versions of PuTTY are versions we think are reasonably likely to work well. However, t up-to-date version of the code available. If you have a problem with this release, then it t the [development snapshots](#), to see if the problem has already been fixed in those version

Package files

You probably want one of these. They include all the PuTTY utilities.

(Not sure whether you want the 32-bit or the 64-bit version? Read the [FAQ entry](#).)

MSI ('Windows Installer')


32-bit: [putty-0.70-installer.msi](#) (or by FTP) 32 bit
(signature)

64-bit: [putty-64bit-0.70-installer.msi](#) (or by FTP) 64 bit
(signature)


- Ensure your manager is connected via USB.




- If you chose TeraTerm, open the program and go to File -> New connection




- Select the serial option presented in the “new connection”
- The serial port you must use is the 3rd of the 4 numbers that the manager occupies (see [Hardware setup](#) if you do not know which COM port to use).
- Choose this option in the Port selection box (shown below).




- Click ok.
- In puTTY, select serial and enter the serial port as the 3rd of the 4 numbers that the manager occupies (see [Hardware setup](#) if you do not know which COM port to use).




- Click open.
- Whether you chose puTTY or TeraTerm, this opens a command prompt. □ Type in “login user” and hit enter.




- Type “minfo” to display information about the manager.




- Enter “set config netid=2425” to change the network ID of the manager to 2425, the same as the in-built network ID of the mote.



- Enter “reset system” to save the changes you have made. Wait until the message “Ready” is displayed as shown.






A screenshot of a Tera Term VT window titled "COM18 - Tera Term VT". The window has a menu bar with "File", "Edit", "Setup", "Control", "Window", and "Help". The terminal text shows a login prompt "login user" followed by several commands and their outputs: "> set config netid=2425", "> reset system" which results in "Reset initiating. Please wait", "> Disconnecting; 1" which results in "111212 : Lost", and "SmartMesh IP Manager ver 1.4.2.2 (x100)" which results in "1186 : **** AP connected. Network started" and "1397 : Active". A cursor is visible at the end of the last line.

```
COM18 - Tera Term VT
File Edit Setup Control Window Help
login user
> set config netid=2425
> reset system
Reset initiating. Please wait
> Disconnecting; 1
111212 : Lost
SmartMesh IP Manager ver 1.4.2.2 (x100)
1186 : **** AP connected. Network started
1397 : Active
█
```

- Type “minfo” again to verify that the network ID has been correctly changed.



A screenshot of a Tera Term VT window titled "COM18 - Tera Term VT". The window has a menu bar with "File", "Edit", "Setup", "Control", "Window", and "Help". The terminal text shows a login prompt "login user" followed by the command "> minfo" and its output: "Net stack 1.4.2.6", "state: Oper", "mac: 00:17:0d:00:00:31:98:ed", "moteid: 1", "netid: 2425", "blSwVer: 15", "ldrSwVer: 0.0.0.0", "board id/rev: 0x7/0x7", "UTC time: 1025665242.729 sec", "reset st: 100", "battery: 3295 mV", and "temp: 30 C". A cursor is visible at the end of the last line.

```
COM18 - Tera Term VT
File Edit Setup Control Window Help
login user
> minfo
Net stack 1.4.2.6
state: Oper
mac: 00:17:0d:00:00:31:98:ed
moteid: 1
netid: 2425
blSwVer: 15
ldrSwVer: 0.0.0.0
board id/rev: 0x7/0x7
UTC time: 1025665242.729 sec
reset st: 100
battery: 3295 mV
temp: 30 C
> █
```

- The manager has now been updated. If the manager is powered before the mote, a connection will be established.