3.5mm-Pitch Push-In Terminal Block PCB Connectors

# 3.5mm-pitch push-in terminal block PCB connectors to greatly improve the efficiency of connector inserting & removing and cable wiring.


- Easy insertion & removal and high contact reliability are achieved with the unique connector engagement structure.
   It contributes to enhanced efficiency of inspection, assembly and maintenance.
- Compatible with through-hole-reflow, good for reflow mounting.
- Standard pin-number printed on the top surface of the socket, no extra spaces needed for pin identification such as on the surface of the PCB.
- Wiring efficiency is improved with the "hands-free" mechanism that keeps screwdriver inserted.
- A coding key for preventing erroneous insertion, a short bar, and a release tool are available as optional parts.











#### List

Model	Single-Row Type, Straight Terminals	Single-Row Type, Right-Angle Terminals	Double-Row Type, Straight Terminals	Double-Row Type, Right-Angle Terminals		
Plug	XW4M-□D1-V1D□	XW4M-□□D1-H1D□	XW4M-□D2-V1D□	XW4M-□□D2-H1D□		
Model	Single-R XW4N-□	 Row Type □□D1.□	Double-Row Type XW4N-□□D2-□			
Socket						

#### **Part Number Structure**

3.5mm-pitch Push-in Terminal Block PCB Connectors

Socket: XW4N-

(1)	(2)	(3)	(4)		
Number of Contacts	1: Single-Row	V1: Straight Terminals	S: Tin Plating		
	2: Double-Row	H1: Right-Angle Terminals	A: Gold Plating		

# **Ratings**

		XW4N-□□D□-□ XW4M-□□D1-□□D□	XW4M-□□D2-□□D□	XW4Z-SD02-BK
	Cross section of solid wire	0.2 mm <sup>2</sup> to 1.5 mm <sup>2</sup>		-
Applicable	Cross section of stranded wire	0.2 mm <sup>2</sup> to 1.5 mm <sup>2</sup>		-
wire ranges *1	Cross section of stranded wire with ferrule with plastic sleeve	0.2 mm <sup>2</sup> to 0.75 mm <sup>2</sup>	-	
	Cross section of stranded wire with ferrule without plastic sleeve	0.2 mm <sup>2</sup> to 1.5 mm <sup>2</sup>	-	
Stripping ler	ngth of solid and stranded wires	9.5 mm MIN	-	
IEC rated vo	oltage (III/3)	160 V	-	
IEC rated cu	ırrent	8 A	-	
Usage grou	p (UG)	B D		-
UL rated voltage		300 V	150 V	300 V
UL rated current		8 A	8 A	
Withstand v	roltage	1,600 VAC 1 min (leakage current: 1 n	-	
Applicable t	tool	XW4Z-00B *2	-	

<sup>\*1.</sup> Refer to page 14 for details of applicable wire ranges and recommended ferrule terminals.\*2. Refer to page 15 for details of recommended tools.

# **Characteristics**

	XW4M/XW4N	XW4Z-SD02-BK	XW4Z-RD02		
Ambient temperature range	-40 to 100°C (with no condensation or icing)	-40 to 100°C (with no condensation or icing) Includes self-temperature rise of the terminal block	-5 to 40°C (with no condensation or icing)		
Ambient humidity range	5 to 85%RH	5 to 70%RH			
Ambient storage temperature	-40 to 70°C (with no condensation or icing)				
Ambient storage humidity	5 to 70%RH				
Connectors mating temperature range	-5 to 40°C (with no condensation or icing)		-		
Connectors mating humidity range	5 to 70%RH	-	-		
Insertion durability	100 times	10 times	-		

# **Materials and Finishes**

# Plug: XW4M

Model Item	Tin Plating XW4M-□□D□-□□DS	Gold Plating XW4M-□□D□-□□DA				
Housing Plug	LCP (UL94 V-0)					
	Copper alloy	Copper alloy				
Plug contact	Terminal part: Tin plating	Terminal part: Tin plating				
	Mating section: Gold plating					
Fastening pins* Copper alloy/Tin plating						
*Fastening pins are	for 10 contacts max. only					

#### Socket: XW4N

Model Item	Tin Plating XW4N-□□D□-S	Gold Plating XW4N-□□D□-A					
Housing cover	PA (UL94 V-0)	•					
<b>Housing Socket</b>	PA (UL94 V-0)	PA (UL94 V-0)					
Lever	PBT (UL94 V-0)						
	Copper alloy	Copper alloy					
Socket contact	Wiring section: Tin plating	Wiring section: Tin plating					
	Mating section: Tin plating	Mating section: Gold plating					
Spring	Stainless steel	Stainless steel					

## Coding key: XW4Z-C001

Model Item		XW4Z-C001
Coding key	PBT (UL94 V-0)	

Short bar: XW4Z-SD02-BK Release tool: XW4Z-RD02

Model Item	XW4Z-SD02-BK	XW4Z-RD02		
Resin part	PBT (UL94 V-0)	Nylon PA		
Terminal part	Copper alloy/Tin plating	-		

# **Standards**

	UL1059
Compliant standard	CSA (C22.2No.158)
	IEC 60947-7-4

# XW4M


# **Dimensions**

CAD Data Please visit our CAD Data website, which is noted on the last page.


(Unit: mm)

CAD Data

#### XW4M-□□D1-V1D□ (straight terminals)



## XW4M-□□D1-H1D□ (right-angle terminals)



Number of contacts	Model (straight)	Model (right-angle)	D	E	Lock pins	Number of contacts	Model (straight)	Model (right-angle)	D	E	Lock pins
2	XW4M-02D1-V1D	XW4M-02D1-H1D□	16.9	3.5	w/	11	XW4M-11D1-V1D	XW4M-11D1-H1D	48.4	35.0	w/o
3	XW4M-03D1-V1D	XW4M-03D1-H1D□	20.4	7.0	w/	12	XW4M-12D1-V1D□	XW4M-12D1-H1D	51.9	38.5	w/o
4	XW4M-04D1-V1D	XW4M-04D1-H1D	23.9	10.5	w/	13	XW4M-13D1-V1D	XW4M-13D1-H1D	55.4	42.0	w/o
5	XW4M-05D1-V1D	XW4M-05D1-H1D	27.4	14.0	w/	14	XW4M-14D1-V1D	XW4M-14D1-H1D	58.9	45.5	w/o
6	XW4M-06D1-V1D	XW4M-06D1-H1D	30.9	17.5	w/	15	XW4M-15D1-V1D□	XW4M-15D1-H1D□	62.4	49.0	w/o
7	XW4M-07D1-V1D	XW4M-07D1-H1D	34.4	21.0	w/	16	XW4M-16D1-V1D	XW4M-16D1-H1D	65.9	52.5	w/o
8	XW4M-08D1-V1D	XW4M-08D1-H1D	37.9	24.5	w/	17	XW4M-17D1-V1D	XW4M-17D1-H1D	69.4	56.0	w/o
9	XW4M-09D1-V1D	XW4M-09D1-H1D	41.4	28.0	w/	18	XW4M-18D1-V1D	XW4M-18D1-H1D	72.9	59.5	w/o
10	XW4M-10D1-V1D	XW4M-10D1-H1D	44.9	31.5	w/	20	XW4M-20D1-V1D□	XW4M-20D1-H1D	79.9	66.5	w/o

# XW4M/XW4N XW4M


# **Dimensions**


CAD Data Please visit our CAD Data website, which is noted on the last page.


(Unit: mm)

CAD Data


# XW4M-□□D2-V1D□ (straight terminals)







# XW4M-□□D2-H1D□ (right-angle terminals)



Number of contacts	Model (straight)	Model (right-angle)	D	E	Lock pins	Number of contacts	Model (straight)	Model (right-angle)	D	E	Lock pins
4	XW4M-04D2-V1D	XW4M-04D2-H1D□	16.9	3.5	w/	22	XW4M-22D2-V1D	XW4M-22D2-H1D	48.4	35.0	w/o
6	XW4M-06D2-V1D	XW4M-06D2-H1D□	20.4	7.0	w/	24	XW4M-24D2-V1D	XW4M-24D2-H1D	51.9	38.5	w/o
8	XW4M-08D2-V1D	XW4M-08D2-H1D□	23.9	10.5	w/	26	XW4M-26D2-V1D	XW4M-26D2-H1D□	55.4	42.0	w/o
10	XW4M-10D2-V1D□	XW4M-10D2-H1D□	27.4	14.0	w/	28	XW4M-28D2-V1D	XW4M-28D2-H1D□	58.9	45.5	w/o
12	XW4M-12D2-V1D	XW4M-12D2-H1D□	30.9	17.5	w/o	30	XW4M-30D2-V1D	XW4M-30D2-H1D	62.4	49.0	w/o
14	XW4M-14D2-V1D	XW4M-14D2-H1D□	34.4	21.0	w/o	32	XW4M-32D2-V1D□	XW4M-32D2-H1D□	65.9	52.5	w/o
16	XW4M-16D2-V1D□	XW4M-16D2-H1D□	37.9	24.5	w/o	34	XW4M-34D2-V1D	XW4M-34D2-H1D□	69.4	56.0	w/o
18	XW4M-18D2-V1D□	XW4M-18D2-H1D□	41.4	28.0	w/o	36	XW4M-36D2-V1D	XW4M-36D2-H1D□	72.9	59.5	w/o
20	XW4M-20D2-V1D	XW4M-20D2-H1D□	44.9	31.5	w/o	40	XW4M-40D2-V1D□	XW4M-40D2-H1D□	79.9	66.5	w/o


# **Ordering Information**





Number of	Plug, Single	-Row, Straight	Plug, Single-R	Plug, Single-Row, Right-Angle			
contacts	Tin Plating	Gold plating	Tin Plating	Gold plating	Quantity (pcs)		
2	XW4M-02D1-V1DS	XW4M-02D1-V1DA	XW4M-02D1-H1DS	XW4M-02D1-H1DA	85		
3	XW4M-03D1-V1DS	-	XW4M-03D1-H1DS	-	70		
4	XW4M-04D1-V1DS	XW4M-04D1-V1DA	XW4M-04D1-H1DS	XW4M-04D1-H1DA	60		
5	XW4M-05D1-V1DS	-	XW4M-05D1-H1DS	-	50		
6	XW4M-06D1-V1DS	XW4M-06D1-V1DA	XW4M-06D1-H1DS	XW4M-06D1-H1DA	45		
7	XW4M-07D1-V1DS	-	XW4M-07D1-H1DS	-	40		
8	XW4M-08D1-V1DS	XW4M-08D1-V1DA	XW4M-08D1-H1DS	XW4M-08D1-H1DA	35		
9	XW4M-09D1-V1DS	-	XW4M-09D1-H1DS	-	35		
10	XW4M-10D1-V1DS	XW4M-10D1-V1DA	XW4M-10D1-H1DS	XW4M-10D1-H1DA	30		
11	XW4M-11D1-V1DS	-	XW4M-11D1-H1DS	-	30		
12	XW4M-12D1-V1DS	XW4M-12D1-V1DA	XW4M-12D1-H1DS	XW4M-12D1-H1DA	25		
13	XW4M-13D1-V1DS	-	XW4M-13D1-H1DS	-	25		
14	XW4M-14D1-V1DS	XW4M-14D1-V1DA	XW4M-14D1-H1DS	XW4M-14D1-H1DA	20		
15	XW4M-15D1-V1DS	-	XW4M-15D1-H1DS	-	20		
16	XW4M-16D1-V1DS	XW4M-16D1-V1DA	XW4M-16D1-H1DS	XW4M-16D1-H1DA	20		
17	XW4M-17D1-V1DS	-	XW4M-17D1-H1DS	-	20		
18	XW4M-18D1-V1DS	XW4M-18D1-V1DA	XW4M-18D1-H1DS	XW4M-18D1-H1DA	20		
20	XW4M-20D1-V1DS	XW4M-20D1-V1DA	XW4M-20D1-H1DS	XW4M-20D1-H1DA	15		





Number of	Plug, Double	-Row, Straight	Plug, Double-F	Row, Right-Angle	Minimum Packaging
contacts	Tin Plating	Gold Plating	Tin Plating	Gold Plating	Quantity (pcs)
4	XW4M-04D2-V1DS	XW4M-04D2-V1DA	XW4M-04D2-H1DS	XW4M-04D2-H1DA	85
6	XW4M-06D2-V1DS	-	XW4M-06D2-H1DS	-	70
8	XW4M-08D2-V1DS	XW4M-08D2-V1DA	XW4M-08D2-H1DS	XW4M-08D2-H1DA	60
10	XW4M-10D2-V1DS	-	XW4M-10D2-H1DS	-	50
12	XW4M-12D2-V1DS	XW4M-12D2-V1DA	XW4M-12D2-H1DS	XW4M-12D2-H1DA	45
14	XW4M-14D2-V1DS	-	XW4M-14D2-H1DS	-	40
16	XW4M-16D2-V1DS	XW4M-16D2-V1DA	XW4M-16D2-H1DS	XW4M-16D2-H1DA	35
18	XW4M-18D2-V1DS	-	XW4M-18D2-H1DS	-	35
20	XW4M-20D2-V1DS	XW4M-20D2-V1DA	XW4M-20D2-H1DS	XW4M-20D2-H1DA	30
22	XW4M-22D2-V1DS	XW4M-22D2-V1DA	XW4M-22D2-H1DS	XW4M-22D2-H1DA	30
24	XW4M-24D2-V1DS	XW4M-24D2-V1DA	XW4M-24D2-H1DS	XW4M-24D2-H1DA	25
26	XW4M-26D2-V1DS	-	XW4M-26D2-H1DS	-	25
28	XW4M-28D2-V1DS	-	XW4M-28D2-H1DS	-	20
30	XW4M-30D2-V1DS	XW4M-30D2-V1DA	XW4M-30D2-H1DS	XW4M-30D2-H1DA	20
32	XW4M-32D2-V1DS	XW4M-32D2-V1DA	XW4M-32D2-H1DS	XW4M-32D2-H1DA	20
34	XW4M-34D2-V1DS	XW4M-34D2-V1DA	XW4M-34D2-H1DS	XW4M-34D2-H1DA	20
36	XW4M-36D2-V1DS	XW4M-36D2-V1DA	XW4M-36D2-H1DS	XW4M-36D2-H1DA	20
40	XW4M-40D2-V1DS	XW4M-40D2-V1DA	XW4M-40D2-H1DS	XW4M-40D2-H1DA	15

# XW4M/XW4N XW4N

# **Dimensions**


CAD Data Please visit our CAD Data website, which is noted on the last page.


(Unit: mm)


XW4N-□□D1-□














Number of contacts	Model	Α	В	С
2	XW4N-02D1-□	15.9	14.5	3.5
3	XW4N-03D1-□	19.4	18	7
4	XW4N-04D1-□	22.9	21.5	10.5
5	XW4N-05D1-□	26.4	25	14
6	XW4N-06D1-□	29.9	28.5	17.5
7	XW4N-07D1-□	33.4	32	21
8	XW4N-08D1-□	36.9	35.5	24.5
9	XW4N-09D1-□	40.4	39	28
10	XW4N-10D1-□	43.9	42.5	31.5
11	XW4N-11D1-□	47.4	46	35
12	XW4N-12D1-□	50.9	49.5	38.5
13	XW4N-13D1-□	54.4	53	42
14	XW4N-14D1-□	57.9	56.5	45.5
15	XW4N-15D1-□	61.4	60	49
16	XW4N-16D1-□	64.9	63.5	52.5
17	XW4N-17D1-□	68.4	67	56
18	XW4N-18D1-□	71.9	70.5	59.5
20	XW4N-20D1-□	78.9	77.5	66.5

# XW4N

# **Dimensions**


CAD Data Please visit our CAD Data website, which is noted on the last page.

(Unit: mm)

XW4N-□□D2-□







Number of contacts	Model	Α	В	С
4	XW4N-04D2-□	15.9	14.5	3.5
6	XW4N-06D2-□	19.4	18	7
8	XW4N-08D2-□	22.9	21.5	10.5
10	XW4N-10D2-□	26.4	25	14
12	XW4N-12D2-□	29.9	28.5	17.5
14	XW4N-14D2-□	33.4	32	21
16	XW4N-16D2-□	36.9	35.5	24.5
18	XW4N-18D2-□	40.4	39	28
20	XW4N-20D2-□	43.9	42.5	31.5
22	XW4N-22D2-□	47.4	46	35
24	XW4N-24D2-□	50.9	49.5	38.5
26	XW4N-26D2-□	54.4	53	42
28	XW4N-28D2-□	57.9	56.5	45.5
30	XW4N-30D2-□	61.4	60	49
32	XW4N-32D2-□	64.9	63.5	52.5
34	XW4N-34D2-	68.4	67	56
36	XW4N-36D2-□	71.9	70.5	59.5
40	XW4N-40D2-□	78.9	77.5	66.5

# **Ordering Information**



Number of contacts	Tin Plating	Gold Plating	Minimum Packaging Quantity (pcs)
2	XW4N-02D1-S	XW4N-02D1-A	190
3	XW4N-03D1-S	-	160
4	XW4N-04D1-S	XW4N-04D1-A	130
5	XW4N-05D1-S	-	110
6	XW4N-06D1-S	XW4N-06D1-A	100
7	XW4N-07D1-S	-	90
8	XW4N-08D1-S	XW4N-08D1-A	80
9	XW4N-09D1-S	-	70
10	XW4N-10D1-S	XW4N-10D1-A	70
11	XW4N-11D1-S	-	60
12	XW4N-12D1-S	XW4N-12D1-A	60
13	XW4N-13D1-S	-	50
14	XW4N-14D1-S	XW4N-14D1-A	50
15	XW4N-15D1-S	-	50
16	XW4N-16D1-S	XW4N-16D1-A	40
17	XW4N-17D1-S	-	40
18	XW4N-18D1-S	XW4N-18D1-A	40
20	XW4N-20D1-S	XW4N-20D1-A	30



Number of contacts	Tin Plating	Gold Plating	Minimum Packaging Quantity (pcs)
4	XW4N-04D2-S	XW4N-04D2-A	133
6	XW4N-06D2-S	-	105
8	XW4N-08D2-S	XW4N-08D2-A	91
10	XW4N-10D2-S	-	77
12	XW4N-12D2-S	XW4N-12D2-A	70
14	XW4N-14D2-S	-	63
16	XW4N-16D2-S	XW4N-16D2-A	56
18	XW4N-18D2-S	-	49
20	XW4N-20D2-S	XW4N-20D2-A	42
22	XW4N-22D2-S	XW4N-22D2-A	42
24	XW4N-24D2-S	XW4N-24D2-A	35
26	XW4N-26D2-S	-	35
28	XW4N-28D2-S	-	35
30	XW4N-30D2-S	XW4N-30D2-A	28
32	XW4N-32D2-S	XW4N-32D2-A	28
34	XW4N-34D2-S	XW4N-34D2-A	28
36	XW4N-36D2-S	XW4N-36D2-A	28
40	XW4N-40D2-S	XW4N-40D2-A	21

# Accessories

#### Screwdriver

Appearance	Model	Description of Application
	XW4Z-00B	Screwdriver for XW4N only.

# Coding key

Appearance	Model	Description of Application
	XW4Z-C001	A coding key that prevents erroneous insertion.

#### **Coding procedure**

Use the following procedure to do the coding.

- (1) Snap off the coding key from the rectangular protection holder. (fig. 1)
- (2) Align the OMRON logo on the coding key with insertion hole as fig.2 and insert the coding key straight into insertion hole of the connector until the end.
- (3) Tilt the holding part and snap off the tip of coding key. (fig.3)




fig.1




fig.2




fig.3

\* If the coding position is wrong or the coding key falls during the process, please extract the coding key with tweezers and retry the coding.

## **Accessories**

#### Short bar

Appearance	Model	Description of Application
	XW4Z-SD02-BK	A short bar for the XW4N. It is used to short-circuit adjacent terminals.

#### Release tool

Appearance	Model	Description of Application
	XW4Z-RD02	A release tool for the XW4Z-SD02-BK short bar.

#### Removing the short bar from the terminal block

Use the following procedure to remove the short bar from the terminal block.

- (1) Hold the release tool at an angle and insert it into the release hole all the way.
- (2) With the release tool still inserted into the release hole, grip the anti-slip part or recessed part of short bar with the finger and withdraw the short bar from the terminal insertion hole. (fig 1)

If you have difficulty grasping the short bar with your fingers due to wires around it, use the tools such as needle-nose pliers. (fig.2)

Be careful not to damage the short bar or surrounding wires during work.

(3) Remove the release tool from the release hole.




Fig 1: Removing the short bar from the terminal block





Fig 2: Removing the short bar from the terminal block with needle-nose pliers.

# **Accessories**


# **Coding pattern**

Connector			XV	V4N					XW	/4M		
Insertion spot/ Coding pattern	(1)	(2)	(3)	(4)	(5)	(6)	(1)	(2)	(3)	(4)	(5)	(6)
1	0	0	0							0	0	0
2	0	0		0					0		0	0
3	0	0			0				0	0		0
4	0	0				0			0	0	0	
5	0		0	0				0			0	0
6	0		0		0			0		0		0
7	0		0			0		0		0	0	
8	0			0	0			0	0			0
9	0			0		0		0	0		0	
10	0				0	0		0	0	0		
11		0	0	0			0				0	0
12		0	0		0		0			0		0
13		0	0			0	0			0	0	
14		0		0	0		0		0			0
15		0		0		0	0		0		0	
16		0			0	0	0		0	0		
17			0	0	0		0	0				0
18			0	0		0	0	0			0	
19			0		0	0	0	0		0		
20				0	0	0	0	0	0			


XW4N (Socket, Single-Row Type)




XW4M (Plug, Single-Row Type)



XW4N (Socket, Double-Row Type)



XW4M (Plug, Double-Row Type)



#### **Precautions**

#### **Definition of Warning and Caution**

Precautions for Safe Use	Indicates the items to be implemented or avoided to ensure a safe use of the product.
Precautions for Correct Use	Indicates the items to be implemented or avoided to prevent failure to operate and malfunctions, and to prevent adversely affecting the performance and function of the product.

#### **Precautions for Safe Use**

- Observe the ratings, specifications and storage conditions.
- Do not drop the product. Doing so may result in the product's failure to fully demonstrate its functions.
- · Do not damage the cores when stripping.
- Do not use in areas subject to high temperatures, high humidity, or toxic gases such as sulfuric gas (H<sub>2</sub>S, SO<sub>2</sub>), ammonia gas (NH<sub>3</sub>), nitric gas (HNO<sub>3</sub>), or chlorine gas (Cl<sub>2</sub>). Otherwise, it can cause corrosive damage to the contacts and result in malfunction.
- Do not use the product in oil or water, or in an environment always subjected to splashes of water or oil. Doing so can cause malfunction due to ingression of water or oil.
- Do not use or store the product in the following environment.
- Places subject to intense temperature change
- · Places subject to high humidity, condensation
- · Places subject to intense vibration
- · Places subject to direct sunlight
- · Places subject to sea breeze
- Do not perform wiring to the release hole.
- Do not tilt or twist the flat-blade screwdriver while it is still inserted into the release hole. Doing so may result in damage to the terminal block.
- Make sure not to drop the flat-blade screwdriver inserted into the release hole.
- Do not forcibly bend or stretch the wire. Doing so may result in wire breakage. In addition, do not apply excessive force to the connector. Doing so will result in poor contact due to damage or deformation.
- Do not insert more than one wire into one terminal (insertion) hole.
- To prevent wiring materials from smoking or ignition, confirm wire ratings.
- Do not touch the product with wet hands.

#### Coding Key

- Do not drop the coding key or touch the tip of key. The tip of key may be damaged.
- When snapping off the tip of the key, do not collide the holding part with the connector. The connector may be damaged.
- When doing the coding, please check the coding pattern carefully. If the coding pattern is wrong it can prevent correct mating of the connectors.
- The coding key is exclusively for the XW4M/XW4N. Do not use it for other connectors.

#### Short bar and release tool

- Do not use the short bar for short-circuiting of the contact between columns. Also, do not insert the short bar into the release hole.
- · Insert the short bar straight, all the way till the end.
- Do not insert the release tool into the terminal insertion hole.
- Do not tilt or twist the release tool while it is inserted into the release hole. Doing so may damage the terminal block and the tool
- Take care not to drop the release tool inserted into the release hole.
- Do not forcibly turn or pull the release tool.
- Do not turn on the power while the release tool is inserted.

#### **Precautions**

#### **Precautions for Correct Use**

- When wiring, please see that no stress will be applied to the product and wires. Secure the wires so that they will not vibrate with the equipment, etc. at set state.
- Do not perform wiring with power turned on.

#### Connecting Wires with Ferrules and Solid Wires

Insert the solid wire or ferrule straight into the terminal block until the end strikes the terminal block. If a wire is difficult to connect because it is too thin, use a flat-blade screwdriver in the same way as when connecting stranded wire.

#### Connecting Stranded Wires


Use the following procedure to connect the wires to the terminal block.

- (1) Hold a flat-blade screwdriver at an angle and insert it into the release hole. The angle should be between 10° and 15°. If the flat-blade screwdriver is inserted correctly, you will feel the spring in the release hole.
- (2) With the flat-blade screwdriver still inserted into the release hole, insert the wire straight into the terminal block until the end strikes the terminal block. At that time, insert the wire at stranded state so that the elements will not be scattered.
- (3) Remove the flat-blade screwdriver from the release hole.

#### Removing Wires

Use the following procedure to remove wires from the terminal block. The same method is used to remove stranded wires, solid wires, and ferrules.


- (1) Hold a flat-blade screwdriver at an angle and insert it into the release hole.
- (2) With the flat-blade screwdriver still inserted into the release hole, remove the wire from the insertion hole.
- (3) Remove the flat-blade screwdriver from the release hole.





PA is used in XW4N housing materials, and the insertion & removal force and the insertion feeling will change depending on the water absorption state.
 Excessive water absorption may result in slight interference with mating components during insertion, but it will not affect the performance and functionality of the product.

#### Inserting and Removing Connectors

- Inserting Connectors
   Insert the connector straight into the plug while pushing the central part of the socket lever. In case of reversed insertion, the connector cannot be inserted to the end.
- Removing Connectors
   Pull off the socket straight from the plug while pushing the central part of the socket lever. Do not pull off by twisting, otherwise damage may result.







Reversed insertion state (NG)

#### **Precautions**

#### **Precautions for Correct Use**

#### Coding Key

- · Please insert the coding key in the right direction until the end of the coding key has been reached.
- Do not use the products in locations subject to high temperature or humidity.
- Do not insert the connector with strong force if mating of the connector is prevented. The connector or coding key may be damaged.

#### Short bar and release tool

- Do not perform wiring with power turned on.
- Do not touch the product with wet hands.
- Do not insert the short bar and the wires into the same insertion hole.
- Do not pull out the short bar using a driver.
- · Do not forcibly gouge out the short bar. Doing so may deform the short bar.
- Do not use the short bar in an environment where electrical hindrance such as static electricity may occur.
- The short bar and the release tool are used exclusively for the XW4M/XW4N. Do not use them with other connectors.
- · Pull out the short bar while keeping the tool pressed. Otherwise, the tool may fall off.

#### Storage

Pay attention to the following during extended storage.

- (1) Do not store in locations subject to dust or high humidity.
- (2) Do not store in locations close to sources of gases such ammonia or sulfide gas.

#### Applicable wire ranges

Wire Type	Ratings	Conductor Length
Solid wire	AWG24 to 16 Cross section: 0.2 to 1.5mm <sup>2</sup>	9.5mm MIN
Stranded wire	AWG24 to 16 Cross section: 0.2 to 1.5mm <sup>2</sup>	9.5mm MIN
Ferrule terminal With plastic sleeve	Cross section: 0.25mm <sup>2</sup> 0.34mm <sup>2</sup> 0.5mm <sup>2</sup> 0.75mm <sup>2</sup>	8mm 8 to 10mm 8 to 10mm 10mm
Ferrule terminal Without plastic sleeve	Cross section: 0.25mm <sup>2</sup> 0.34mm <sup>2</sup> 0.5mm <sup>2</sup> 1.0mm <sup>2</sup> 1.5mm <sup>2</sup>	7mm 7mm 8 to 10mm 8 to 10mm 8 to 10mm 10mm

#### Recommended Ferrule Terminals


· With plastic sleeve

		Manufacturer			
		Phoenix Contact	Weidmuller	Wago	
Cross section	0.25mm <sup>2</sup>	Al 0.25-8	H0.25/12	FE-0.25-8N-YE	
	0.34mm <sup>2</sup>	AI 0.34-8 AI 0.34-10	H0.35/12	FE-0.3-8N-TQ	
	0.5mm <sup>2</sup>	AI 0.5-8 AI 0.5-10	H0.5/14D	FE-0.5-8N-WH	
			H0.5/16D	FE-0.5-10N-WH	
	0.75mm <sup>2</sup>	Al 0.75-10	H0.75/16D	FE-0.75-10N-GY	
Crimping tool		CRIMPFOX 6	PZ 6 ROTO	Vario crimp4*1	

· Without plastic sleeve

		Manufacturer		
		Phoenix Contact	Weidmuller	Wago
Cross section	0.25mm <sup>2</sup>	A 0.25-7		
	0.34mm <sup>2</sup>	A 0.34-7		
	0.5mm <sup>2</sup>	A 0.5-8 A 0.5-10	H0.5/14	
	0.75mm <sup>2</sup>	A 0.75-8 A 0.75-10	H0.75/10	
	1.0mm <sup>2</sup>	A 1-8 A 1-10	H1.0/10	FE-1.0-10
	1.5mm <sup>2</sup>	A 1.5-10	H1.5/10	
Crimping tool		CRIMPFOX 6	PZ 6 ROTO	Vario crimp4*1

- The crimping tool can only be used for 0.25 to  $1.0 \text{mm}^2$  ferrule terminals. The crimping height (H) of ferrule terminals is 1.5 mm or less. In addition, the width (H) of ferrule terminals is 2.5mm or less. However, it is limited to crimping shapes obtained using applicable crimping tools.



## **Precautions**

#### Recommended Flat-Blade Screwdrivers

Use a flat-blade screwdriver to connect and remove wires.

Use the following flat-blade screwdrivers.

The following table shows manufacturers and models as of December 2020.

Model	Manufacturer	
ESD 0.40 × 2.5	WERA	
SZS 0.4 × 2.5	PHOENIX CONTACT	
SZF 0-0.4 × 2.5*		
0.4 × 2.5 × 75 302	WIHA	
AEF.2.5 × 75	FACOM	
210-719	WAGO	
SDI 0.4 × 2.5 × 75	WEIDMULLER	
9900 (-2.5-75)	VESSEL	

<sup>\*</sup> SZF 0-0.4×2.5 (Phoenix Contact) can be arranged from OMRON's special model (XW4Z-00B).

#### Recommended Reflow Conditions

Peak temperature: 250°C

220°C or above 45 to 90 seconds

Preheating: 150°C to 180°C

60 to 120 seconds

The solderability is not guaranteed, as above conditions may change depending on type and amount of solder, and type of flux

# **Approval Standard**

The approval rating values for overseas standards are different from the performance values determined individually. Confirm the values before use.

Model	Standard	File No.	Rating
XW4M-□□D1-V1D□	UL/C-UL certified product (Recognized)	E245101	UG: B, D, 300 V, 8 A
XW4M-□□D1-H1D□	UL/C-UL certified product (Recognized)	E245101	UG: B, D, 300 V, 8 A
XW4M-□□D2-V1D□	UL/C-UL certified product (Recognized)	E245101	UG: B, 150 V, 8 A UG: D, 300 V, 8 A
XW4M-□□D2-H1D□	UL/C-UL certified product (Recognized)	E245101	UG: B, 150 V, 8 A UG: D, 300 V, 8 A
XW4N-□□D1-□	UL/C-UL certified product (Recognized)	E245101	UG: B, D, 300 V, 8 A
XW4N-□□D2-□	UL/C-UL certified product (Recognized)	E245101	UG: B, D, 300 V, 8 A
XW4Z-□□B	Non-certified product	-	-
XW4Z-C001	Non-certified product	-	-
XW4Z-SD02-BK*	Non-certified product	-	-
XW4Z-RD02	Non-certified product	-	-

<sup>\*</sup> Contact OMRON to check the safety standard conditions.

Please check each region's Terms & Conditions by region website.

OMRON Corporation
Device & Module Solutions Company

## **Regional Contact**

Americas

https://components.omron.com/us

Asia-Pacific

https://components.omron.com/ap

https://components.omron.com/kr

Europe

https://components.omron.com/eu

China

https://components.omron.com.cn

Japan

https://components.omron.com/jp