search

DFRobot Products (DFR) Index
Sensor (SEN) Index
Telecom Module (TEL) Index
Motor Driver (DRI) Index
Fitting (FIT) Index
Robot (ROB) Index
micro:bit (MER) Index
Kit (KIT) Index
Toy (TOY) Index
Sensor (SEN) Index
What's DF series
How to select series
How it works series
FirstFrog Library


Introduction
Tutorial
Preparation
Product wiring instructions
Power-up preview
PC side preview interaction
Comtool configuration instructions
Case
FAQ
Secondary development Serial protocol
Secondary development Access ROS
More Documents

SKU:SEN0581



ntroduction

The 3D TOF depth camera is composed of ELTO and Ioyou 1Mx160 SoC and is a 3D sensor that can measure distances up to 10m, 60 fps and is 11.4 inch (2) screen allows for real-time preview. It supports USB 3.0 interface and is backward with USB 2.0 through UART and Type-C interfaces. It supports ROS system (ROS1+ROS2), enabling fast acquisition of depth data and depth maps. An integrated, cost-effective, and user-friendly 3D Time-of-Flight (ToF) solution designed specifically for Internet of Things (IoT) applications. This solution encompasses various algorithms that enable distance measurement, multi-zone body positioning and tracking, and gesture recognition, and can be seamlessly integrated into customer products. These features find wide ranging applications in numerous fields, including white goods, beer, televisions, smart projectors, intelligent lighting, smart parking systems, and home automation facilities.





Tutorial

Preparation

Uses the serial port protocol to provide interfaces and transmit data.

The physical interfaces we provide include type-c (virtual serial port) and 1.0mm 4pin motherboard (UART), which can obtain depth map data in real time.

Product wiring instructions

After connecting to the computer through the type-c interface, it can identify /dev/ttyUSBx (Linux) or COMx (Windows).



The usb2tll module can also be used to connect the 4 PIN bus according to the hardware pin diagram (device screen face down).

SEN0581	TX	RX	GND	5V
USB TTL	RX	TX	GND	5V

Power-up preview

Button function: 'Next' on the left and 'Switch' on the right.

Screen display: the + word in the center of the screen is the ranging point, and the top right will display real-time ex on on behalf of the distance ranging. If there is a large area of objects near the lens, 'block' will be displayed on the right of the screen. In other cases open!

After the device is connected to the computer, you can preview the depth pseudo-color map in real time on the built-in LCD screen of the device.



PC side preview interaction

Install COMTOOL on the upper computer before previewing and modifying the Settings via the PC.

Windows system:comtool-windows

Linux system:https://github.com/sjwest/AhtoSense-ComTool

Note: Windows 7 and below systems need to install the driver, you can go to the FTDI official website to download.

Open the COMTOOL software and select the Graph interface. If there is no Graph above the software, you can add a Graph at the + sign in the upper right corner. If the middle part is blank after creation, double-click YokaSnesw.ko in the lower left corner.



Select a small Port and baud rate in the left port (choose any high baud rate), click open and check USB to receive a large amount of data. Connected will be displayed in the lower left corner



Set the Header to \x55\xff to correctly parse the image data and observe the depth map to intuitively feel the depth on the ZD to image.



Comtool configuration instructions

Comtool configuration control description of the host computer

- **Header**:set the identification header.
- **Baud**:RS485(can be set commands manually (USB and UART serial ports behave the same).
- **Off**:start stop.
- **LED**:display the led screen on and off.
- **USB**:serial port transmission depth map on and off.
- **UART**:serial port transmission depth map on and off.
- **ANOTHER**:Automatic anti-multi-machine interference is turned on and off (susceptible to interference, the effect of turning off is better).
- **Boot**:pull down to set BYAVING, Baud to set UART baud rate.
- **A**, **F**:coordinatesWhen the checkbox to the left of D is on, the D,D distance from the camera is displayed.
- **Compress**:Image compression, from uncompressed to 8-bit, the scale is reduced. If the setting is not used, only very close images can be seen clearly.
- **FPS**:Set the output frame rate.It should not be too high, set it reasonably according to the performance of the docking device, reducing the frame rate can reduce the amount of transmitted data)
- **Exposure**:gap control (without represents AE, others are fixed exposure time)

Case

Measure Objects Distance

The distance between the objects is placed to form the difference in depth value. After the module captures the difference, it displays a warm and cold color, a warm color when the distance is close, and a cool color when the distance is far.



Gesture Interaction

Realize super cool keyboard light follow,track the position of the hand in real time,and then map the keyboard light according to the position of the hand.

Related code



Secondary development Serial protocol

Secondary development manual

Secondary development Access ROS

1.Access ROS1

Preparations

First, prepare the applicable environment Linux system.

You can use the virtual machine virtual box or vmware.

Install and run

ROS Access Package: vipeed_tof_ms_a010_ros_v0.3.zip

```
# Unzip vipeed_tof_ms_a010.zip and enter the directory
cd ros1
source /opt/ros/*/setup.sh
catkin_make
source devel/setup.sh
roscm vipeed_tof_ms_a010 a010_publisher _device:="/dev/ttyUSB0
# After that, the terminal will continue to refresh and displa
```



You can view the frame rate in RQT



RVIZ2 Preview

After opening rviz2, in the lower left corner of the interface Add-> By topic->/PointCloud2 or /depth -> Image Add -> Display/Global Options/Fixed Frame needs to be modified to tof, the point cloud can be displayed normally. According to the added content, Image will be displayed on the left and the point cloud will be displayed in the middle.



2.Access ROS2

Preparations

First, prepare the applicable environment Linux system.

You can use the virtual machine virtual box or vmware.

If your environment also has ROS1 installed, ROS2 will need to be used with the correct version.

```
ls /opt/ros
roughly:virtual-machine:~/Desktop$ ls /opt/ros
humble  melodic
```

Install and run

We provide an access package for ROS2, which users need to compile and install on a system running ROS2. ROS Access Package:vipeed_tof_ms_a010_ros_v0.3.zip

```
#Unzip vipeed_tof_ms_a010.zip and enter the directory
cd ros2
source /opt/ros/*/setup.sh
#If you install TOF you are prompted that colcon is missing, you
source install/setup.sh
ros2 run vipeed_tof_ms_a010 a010_publisher --ros-args -p device:=
# After that, the terminal will continue to refresh and displa
```

RQT View frame rate



RVIZ2 Preview

After opening rviz2, in the lower left corner of the interface Add-> By topic->/PointCloud2 or /depth -> Image Add -> Display/Global Options/Fixed Frame needs to be modified to tof, the point cloud can be displayed normally. According to the added content, Image will be displayed on the left and the point cloud will be displayed in the middle.

More Documents

- comtool-windows
- Secondary development manual