search
DFRobot Products (DFR) Index
Sensor (SEN) Index
Telecom Module (TEL) Index
Motor Driver (DRI) Index
Fitting (FIT) Index
Robot (ROB) Index
Micro:bit (MB) Index
Kit (KIT) Index
Toy (TOY) Index
Sensors (SEN) Index
What is 3S series
How to select series
How it works series
FireFeng Library

Introduction
Preparation
On page preview
Interactive configuration
Save data
SSH login
Case
Custom development
Use ROS
Use ROS1
Use ROS2
More Documents

SKU:SEN0583

Introduction

The RGB-D camera is based on the principle of Right-Only camera module equipped with USB capabilities that combines depth measurement and RGB image capture (optional microphone), utilizing a

simple USB data connection, this camera module effortlessly delivers ToF depth data and RGB images at a remarkable speed of 30 frames per second. With the aid of a web based control interface, users can effortlessly adjust various depth data and, experience real-time, vibrant 3D visualization. Moreover, it offers effortless plug-and-play functionality on Linux systems, eliminating the need for any additional drivers. It seamlessly integrates with ROS, Python, and OpenCV, enabling image capture, sample codes, and a Python SDK for secondary development kit. GUIDE. Leveraging the acquired point cloud data, various applications such as 3D facial recognition, object scanning, and AR/VR hand tracking can be realized with unparalleled precision.

An integrated, cost-effective and user-friendly 3D Time-of-Flight (ToF) solution designed specifically for Internet of Things (IoT) applications. This solution encompasses various algorithms that enable distance measurement, multi-zone body positioning sensing, posture detection, posture control, and essential calibration functionalities. These features find wide-ranging applications in smart home devices, robotics, drones, logistics, telepresence, smart products, intelligent lighting, smart parking systems, and home automation facilities.

Preparation

To run preview module on Windows, install the driver.

Windows Installation driver tutorial:Click to view

On-page preview

Before using this device, make sure that the 192.168.233.0/24 address segment is not occupied in your network environment, because the MS-A0701V uses RNDIS and sets its IP address: http://192.168.233.1.

Please connect the camera to the PC with power according to the figure above, then the built-in fan will start to work and the red light will be displayed at the lens. Select the browser and enter http://192.168.233.1 to preview the 3D point cloud image. After power-on, the system and program will be started 10s-15s delayed.

Quick preview using web-zupper computer (front and side):

We can preview the depth pseudo-color point cloud map. Open the interaction panel in the upper-right corner, uncheck RGB_Map in the Root line.

Interactive configuration

The preview webpage contained many function configurations, we can change them to get different fine preview result.

Here tells the functions of each widgets.

- **RGB_Map** checkbox, control RGB map. Display the deep pseudo-colored point map when checked; display the RGB-mapped point cloud map when unchecked.
- **colorMap** drop-down bar, provides several pseudo-color mapping options(map1 ... jet is recommended. Available when RGB_Map is unchecked.
- **dropRangeMax** and **dropRangeMin** slide bar are used for setting the mapping range of cmap, the depth value between dropRangeMin and dropRangeMax are ON. Available when RGB_Map is unchecked.
- **NormalPoint** checkbox, control the display of normal point(There maybe some installation points when TOF worked, need to do opposite action). Recommend checked.
- **OE_Points** checkbox, control the display of OE point. Recommend unchecked.
- **UE_Points** checkbox, control the display of UE point. Recommend unchecked.
- **Bad_Points** checkbox, control the display of bad points. Recommend unchecked.
- **SpatialFilter** checkbox, control the Spatial Filtering. Processing based on the spatialFilterSize value below and the algorithm specified by the spatialFilterType.
- **TemporalFilter** checkbox, control the Temporal filtering. A time average is calculated based on the temporalFilterValue below.
- **TemporalFilterAlpha** slide bar, set the time for Temporal Filtering. Adjust it moderate, can be tested by yourself.
- **SpatialFilterType** drop-down bar, set the Spatial Filtering algorithm, provides Gaussian filtering and Bilateral filtering. Bilateral filtering requires high performance. recommended.
- **SpatialFilterSize** slide bar, set the range for Spatial Filter. Adjust it moderate, can be tested by yourself.
- **FlyingPointFilter** checkbox, control the flying point filter. Set the the following FlyingPointThreshold value as the filtering threshold, those that exceed the threshold will be filtered out. Set it moderate, otherwise the validation points will be filtered out.

Save data

The webpage provides 2 buttons at the bottom of the control bar.

- **SaveRaw** : Save one frame raw data. If you want to use the depth data or IR or RGB data for development, you need to know the data struct of raw. We provide a detailed jupyter notebook about the data processing of raw data for secondary developers.
- **SavePointCloud** : Save one frame 3D point map, and its saved format is ply. Can be previewed via the script provided above.

Note: The data of raw can be get through open interface, which developers can do development on. While the pointcloud data does not provide any interface since it's calculated based on the raw data and camera internal parameters.

SSH login

In addition to using the web page to preview directly, we can also login using SSH with password root

In the web preview page we know the ip address of this device is 192.168.233.1, with which we can login to this device.

```
ssh root@192.168.233.1
```

Case

Real shooting of distant, near and far point cloud

High-precision mapping of differences in object placement distances, point cloud maps can intuitively feel a more realistic visualization.

Custom development

python SDK

This is a SDK based on Python3. MS-A0701V opens its http interface, we can get its origin data (Depth map is map, rgb map) through http request.

To help user understand the struct of data package and the relevant logic of decoding, we provide decoding method in python, and encapsulate http requests and native data. With it users can do custom development.

Get SDK:Click to download

Method: Install spyder, connect to the TCP module, then open the tutorial.py file.

Decode and stream

After understanding the struct of data package and the relevant logic of decoding from Python SDK, we can do advanced development, continuously get, decode and will get the depth point python image library, like matplotlib for live display. The tutorial.py gives a demonstration of getting one frame data, and it can achieve live display by pil with loop.

Decoding and streaming:Click me to see content of stream.py

Methods: Run command *python stream.py* after installing all dependent packages.



Detect volume

Based on third-party python library, and have understood the logic of getting and decoding data, we can do more development. Continuously display frames, roughly calculate the point cloud through the data from TOF module by SDK, do the accumulation to get the total volume. Limit: The top view should include all threads detection.

Detect volume: Click to view *calVolume.py*

Methods: Run command *python calVolume.py*, after installing all dependent packages, there will be notice after you run it.

Use ROS

To begin this, install ROS on your computer first.

Use ROS1

Preparation

Prepare a Linux environment for ROS.

Install and RUN:

Access package download.

```
#Extract sipeed_tof_ros1.zip, and open its path
source /opt/ros/*/setup.sh
catkin_make install
source devel/setup.sh
roslaunch sipeed_tof_ros1 pub2.launch
#Then the terminal continuously refreshes the command line
```

View frames in RQT

A RVIZ preview

Open rviz1 in the bottom left interface choose Add -> By topic -> /PointCloud2 ->ok(depth -> /depth/PointCloud2 Options/Fixed Frame, changed it into tof. In this way it displays point cloud normally. According to the added frames in the image displays in the left and the point cloud display in the center.

Use ROS2

Preparation

Prepare a Linux environment for ROS.

Install and RUN:

We have provided the functional package for ROS2, users need compile and run it on the system with ROS2.Access package download.

```
#Extract sipeed_tof_ros2.zip, and open its path
source /opt/ros/*/setup.sh
#Compile, if there is any missing colcon, use command sudo
source install/setup.sh
ros2 run sipeed_tof_ros2 pub2node
#Then the terminal continuously refreshes the command line
```

View frames by RQT

Open RQT and select Plugins -> Topics -> Topic Monitor.

RVIZ2 Preview

Open rviz2 in the bottom left interface choose Add -> By topic -> /PointCloud2 ->ok(depth -> /depth/PointCloud2 Options/Fixed Frame, changed it into tof. In this way it displays point cloud normally. According to the added frames in the image displays in the left and the point cloud display in the center.

The result of mixing Pseudo-colored point clouds and RGB:

Open RQT and select Plugins -> Topics -> Topic Monitor.

More Documents