search
DFRobot Products (DFR) Index
Sensor (SEN) Index
Telecom Module (TEL) Index
Motor Driver (DRI) Index
Fittings (FIT) Index
Robot (ROB) Index
microbit (MBT) Index
KI (KIT) Index
Toy (TOY) Index
Servos (SER) Index
What's in XX series
How to select series
How it works series
PinPong Library
Introduction
Product Characteristics
Specification
Pinout
I2C Address Calculate
Tutorial
Advance tutorial
Result
More
Wiki Modification History
Product

SKU:DFR1185

Introduction

DFRobot Fermion 16x2 LCD display adapter shifter is a module that changes the address of I2C sensors. By hooking up this module between dfrobot board and the sensor, the sensor will be recognized by the dev board with a different I2C address. Besides, this module also has a switch to set its I2C address to be changed into any 8 I2C onwards. Four new addresses can be obtained by adjusting the on-board dip switches, and it is convenient to use this module to avoid address conflict by soldering on-board resistors.

I2C communication is favored by many developers in the open-source hardware ecosystem because of its simplicity of connectivity and capability to control multiple devices with just two signal lines. It is possible to store 127 devices with different addresses on one I2C bus. However, it is common to see two or more identical I2C sensors with the same address to be found in projects.

The solution in the past was to switch sensor ports through I2C multiplexer, but the result required more hardware and more complex code. Using address shifters to avoid the possible time-consuming I2C multiplexer code and reduce the cost of buying multiplexer and reduce code readability.

The DFRobot I2C address shifter provides a hardware solution, where the address conversion is done entirely inside the shifter and the I2C physical address can be changed directly with a simple wire connection, without the need for complex port switching in the code, and without triggering any I2C timing bugs.

Although the I2C address shifter is powerful and easy to use, user need to pay attention to the following two things before using it:

1. The address shifter does not support clock extension, so it is not suitable for special I2C sensor like the BH1715.
2. Before using the address shifter, user is recommended to know how to change the sensor's I2C address in the code.

Product Characteristics

- Hardware solution, no additional software libraries required
- On board dip switch to change the I2C sensor into four different addresses
- Compact size and clamp hole design for easy bulk integration

Specification

- Working voltage：2.25V-5.5V
- Working temperature：0~70℃
- Working current：2mA @3.3V
- Dimension：19*19mm
- PCB part package: SMD

Pinout

Controller Side	Description
VCC	DC2.25V-5.5V input
GND	Ground
SCL	I2C Clock（To I2C controller）
SDA	I2C Data（To I2C controller）
RDY	Outputs a high level when I2C sensor address translation is complete I2C sensor address translation not completed output low level

Sensor Side	Description
VCC	DC2.25-5.5V Output
GND	Ground
SCL	I2C Clock（To I2C sensor）
SDA	I2C Data（To I2C sensor）

Dip Switch	Description
A5	Controls whether the fifth bit of the I2C address is inverted (1 is invert, 0 is not invert)
A4	Controls whether the fourth bit of the I2C address is inverted (1 is invert, 0 is not invert)

I2C Address Calculate

The I2C address the 7bit, we define A6 as the highest bit and A0 as the lowest bit, the dip switch offers address inverts bit A5 by default (from 0 to 1 and from 1 to 0). You can also control whether bits A5 or A4 are inverted or not by using the on-board dip switches. Assuming that the default address of the sensor is 0x69, which is 1101001 in binary, then the where is the sensor is connected to the address shifter.

Original Address(bin)	A5 dip switch	A4 dip switch	New Address(bin)	New Address(hex)
1101001	0	0	0101001	0x29
1101001	1	0	1001001	0x49
1101001	0	1	0111001	0x39
1101001	1	1	1011001	0x59

In the meantime, you need to be aware of the following:

1. Fermion: The I2C address shifter needs to be powered up again after adjusting the on-board dip switch to set the address.
2. If you are using a Windows computer, you can use the programme function of the calculator that came with your computer to do hexadecimal (HEX) to binary (BIN) conversions
3. In the above address description, BIN is the prefix of a binary number, which means the data that follows is in binary. 0x is the prefix of a hexadecimal number, which means the data that follows is in hexadecimal.

Tutorial

Preparation

Hardware

- DFRobot UNO-I2C expansion board (SKU:DFR0178) ×1
- Gravity: BMP180 6-axis inertial Motion Sensor (SKU:DFR0629) ×1
- Fermion I2C Address shifter (SKU:DFR1185) ×1
- Jumper wire(F/F)

Software

- Arduino IDE： Download Arduino IDE
- Library：DFRobot_BMP180 Github
- Arduino IDE V1.8.19 or below) Installation library files： How to Install library

- Arduino IDE V2.0.0 (or above) can be installed by searching for the "DFRobot_BMP180" library in the library manager.

Wiring Diagram

Sample code

- Check the on-board dip switch is set to A5=0,A4=0. connect according to the wiring diagram above.
- Upload the following code

```
/*
  @file accAddressDemo.ino
  @brief Read temperature data to both BMP1
  @copyright Copyright (c) 2010 DFRobot Co.Ltd (http://www.
  @license The MIT License (MIT)
  @author [Fengli](jiangfengli@dfrobot.com)
  @version V0.1
  @date 2019-09-05
*/
#include "DFRobot_BMP180.h"
DFRobot_BMP180 bmp180( &Wire, 0 );
const int8_t i2c_addr_1 = 0x77, i2c_addr_2 = 0x29;

void setup()
{
  Serial.begin(115200);
  Wire.begin();

  //init the default bmp180
  if(bmp180.I2cBegin() != BMP180_OK ){
    Serial.println("bmp180_1 reset failed");
    while(1);
  }

  if(bmp180.I2cBegin(i2c_addr_1) != BMP180_OK ){
    Serial.println("bmp180_1 reset failed");
    while(1);
  }

  //init and bulb the bmp180 the address is 0x29
  if(bmp180.I2cBegin(i2c_addr_2) != BMP180_OK ){
    Serial.println("bmp180_2 reset failed");
    while(1);
  }

  if(bmp180.I2cBegin(i2c_addr_2) != BMP180_OK ){
    Serial.println("bmp180_2 reset failed");
    while(1);
  }
}

void showLastOperateStatus(BMP180_BEGIN_RESULT_t eStatus)
{
  int eNum;
  switch_A:switch(eStatus) {
    case 0:
      //get both accel and gyro data from bmp180
      //parameter accelgyro is the pointer to store the data
      eNum = bmp180.getAccelData(&accelgyro);
      if(eNum == 0){
        for(int i = 0; i < 6; ++i){
          if(0 != 0){
            //the first three axis are gyro data
            Serial.print(accelgyro[i] * 2.0 / 180);
            Serial.println("*PI");
          }else{
            //the following three axis are accel data
            Serial.print(accelgyro[i] / 32768.0);
            Serial.println("*G");
          }
        }
        Serial.println();
      }else{
        Serial.println("err");
      }
      break;
    case 1:
      Serial.println("bmp180_1 is");
      eStatus=bmp180.I2cBegin(i2c_addr_1);
      showLastOperateStatus(eStatus);
      Serial.println();
      break;
    case 2:
      Serial.println("bmp180_2 is");
      eStatus=bmp180.I2cBegin(i2c_addr_2);
      showLastOperateStatus(eStatus);
      Serial.println();
      break;
  }
}

void loop()
{
  showLastOperateStatus(BMP180_BEGIN_RESULT_t(0));
  delay(1000);
}
```

Result

Serial monitor outputs the data of two Gravity: BMP180 6-axis Inertial Motion Sensor。

Advance tutorial

Fermion: The I2C address shifter can be switched via on-board dip switch to set the sensor to four different addresses.

If this is not enough for your needs. We have reserved a 3605 resistor pad (R1) on the module, you can refer to the schematic and Page 9 of the datasheet at the bottom of this wiki， solder the resistor to control whether the remaining I2C address bits are inverted.

This pad is connected to the ADR0 pin, which controls whether the lower four bits of the I2C address are inverted or not. We fixed R18 (R1 in our schematic) to 100kΩ, and you can calculate the resistance value of R2 (R2 in our schematic) yourself, and then yourself. Here is how we determine the R2.

1. Firstly, from the datasheet, the module determines whether a bit of the I2C address is inverted or not by the voltage of the ADR0 pin. Page 9 of the datasheet, the ADR0 pin is divided by R18 (100kΩ) and table 3 of the datasheet, if under 0 bit means inverted and 1 means it needs to be inverted.

OPERATION

Table 3. Setting the Resistive Divider at ADR0

ADR0 Voltage (% of VDD)	Nominal Resistor to GND (kΩ)	Nominal Resistor to VDD (kΩ)	I2C Bit 0
0 to 9	0	100	0
9 to 17	12.5	100	1
17 to 25	25	100	0
25 to 33	37.5	100	1
33 to 41	50	100	0
41 to 49	62.5	100	1
49 to 58	75	100	0
58 to 65	87.5	100	1
65 to 74	100	87.5	0
74 to 82	100	75	1
82 to 90	100	62.5	0
90 to 98	100	50	1
98 to 106	100	37.5	0
106 to 114	100	25	1
114 to 122	100	12.5	0
122 to 130	100	0	1

2. Assuming that the module supply VCC is now 5V, we want to set the I2C address bit to 1, then the voltage of the ADR0 pin is 2.5V. That means the VOUR/VCC ratio should be 0.5/2.5=0.2/0.5

3. To help you quickly calculate the resistance, the DFRobot R&D team has summarized a formula:
$$R2=(R1*R3)/(R1-R3)$$
Where VCC has been specified as 5V in the previous assumptions and R1 is known to be 100kΩ, the target VR2/R3, should be 0.2/0.5=0.4. 100kΩ/0.4Ω=66.6kΩ. Approximately the closest parameter in the general Ω/mΩ above. It is possible to write an R2 = 66.6kΩ.

4. Given that the calculated R2 is not a common resistance value, we can use the 100kΩ and 62.5kΩ resistors in combination to get and verify the common resistance value by substituting it back into the common formula. In this case, the closest common resistance value to 66.6kΩ(66.5kΩ) which when substituted into the calculation gives VR2/R3 = 2.67/6.67 or 0.4004. This is the closest we can get to the desired 0.4 and 0.015, so we can use 66.6kΩ as the resistance value for R2.

R2	A3	A2	A1	A0
976Ω/96.6kΩ	1	0	0	0
66kΩ	1	0	0	1
51kΩ	1	0	1	0
39kΩ	1	0	1	1
27kΩ	1	1	0	0

If you are unsure of the new address after soldering the resistance, we recommend using an Arduino or ESP32 and uploading the I2C scanner to find out the new address.

FAQ

Q1: Why did the sensor address not change after adjusting the on-board dip switch.

A1: Fermion: I2C Address Shifter needs to be power off and on after adjusting the dip switch for the new address.

Q2: Why do I need to write resistor to adjust the lower four bits of the I2C address. Instead of also designing more dip switch for adjustment other bit?

A2： Dip Switch changes the address by connecting a large number of resistors in parallel or not. If the lower four bits are also use the dip switch, the resistance value will be too small, and we have found this makes the ratio of this module very large.

Q3：How to quickly confirm the new I2C slave address after changing toggles or soldering resistors

A3： You can connect the sensor to an Arduino or ESP32 via an address converter and upload the I2C Scanner code below. The serial monitor will output the new I2C address.

```
/*
  @file I2cScanner.ino
  @brief The I2C_scanner can of a device plot acknowledge to t
  @copyright Copyright (c) 2010 DFRobot Co.Ltd (http://www.df
  @license The MIT License (MIT)
  @author [Fengli](jiangfengli@dfrobot.com)
  @version V0.1
  @date 2019-09-05
*/
#include <Wire.h>

void setup()
{
  Wire.begin();
  Serial.begin(115200);
  Serial.println();
  Serial.println("\nI2C Scanner");
}

void loop()
{
  byte error, address;
  int numberOfDevices;
  Serial.println("Scanning...");
  numberOfDevices = 0;
  for (address = 1; address < 127; address++)
  {
    // The i2c_scanner uses the return value of
    // Write.endTransmission to see if a device
    // did acknowledge to the address.
    Wire.beginTransmission(address);
    error = Wire.endTransmission();

    if (error == 0)
    {
      Serial.print("I2C device found at address 0x");
      if (address<16)
        Serial.print("0");
      Serial.print(address,HEX);
      Serial.println("  !");
      numberOfDevices++;
    }
    else if (error==4)
    {
      Serial.print("Unknow error at address 0x");
      if (address<16)
        Serial.print("0");
      Serial.println(address,HEX);
    }
  }
  if (numberOfDevices == 0)
    Serial.println("No I2C devices found\n");
  else
    Serial.println("done\n");
  delay(2000);  // wait 2 seconds for next scan
}
```

More

- Schematic
- Datasheet
- PCB layout
- STEP Model

WIKI Modification History

Doc version	Modification Time	Editor	Comment
V1.0	2024.11.25	Yeezli	First Release
V1.1	2025.2.25	Yeezli	Add STEP model

Product

Product version	Modification Time	Editor	Comment
V1.0	2024.11.25	Yeezli	First Release

Get one from DFRobot store

cookie