


Coaxial Cable Stripper 2 - Blades Model



The V-block can be reversed, and the indication arrow ">" shows recommended cable size. Stripping distance can be changed if user moves one of the stripping blades. (AS FIG. 2)

Stripping the coaxial jacket and inner conductor in one operation by rotating the stripper in clockwise direction 3-6 times, easy and effective.

For stripping different materials of cable, use the built-in hex key to align the sensitive socket and adjust the blade for good results.

HT-	FOR STRIPPING RG CABLE	STRIPPING DISTANCE
332	RG-58/59/62/6/6QS/3C/4C/5C	2 BLADES MODEL  Fig. 2 302 SERIES D=6, 8mm 332 SERIES D=4, 6, 8, 12mm
332A	RG-59/62/6/4C/5C	
332B	RG-58/59/62/3C/4C	
332D	RG-174	
302A	RG-59/62/6/4C/5C	
302B	RG-58/59/62/3C/4C	
322S	RG-8/11/213	

Replacement Blade:

HT-302 series -- HT-3021, HT-312 series -- 3121

HT-332 series -- HT-3321, HT-322 series -- 3221

Special requirement is available.