

DEMO MANUAL DC1859A

# LTC3124 Dual Phase Synchronous Step-Up DC/DC Converter

# DESCRIPTION

Demonstration circuit 1859A is a dual phase single output DC/DC boost converter featuring the LTC<sup>®</sup>3124. The DC1859A operates over 1.8V to 5.5V input and generates 12V at up to 1.5A from a 5V input. The maximum output current for a 1.8V input is 750mA. Also, the LTC3124 has a 2% precise voltage reference, which can generate an output voltage with 2.2% tolerance if 0.1% voltage divider resistors are used. The 1MHz switching frequency operation results in small and efficient circuit. The converter operates with only one phase in Burst Mode<sup>®</sup> operation

# and achieves over 90% efficiency with a 100mA load. The demonstration circuit can be easily modified to generate different output voltages.

The DC1859 has small circuit footprint. It is a high performance and cost effective solution for generating output voltages up to 15V from inputs as low as 1.8V.

# Design files for this circuit board are available at <a href="http://www.linear.com/demo/DC1859A">http://www.linear.com/demo/DC1859A</a>

**Δ7**, LT, LTC, LTM, Linear Technology, Burst Mode and the Linear logo are registered trademarks of Linear Technology Corporation. All other trademarks are the property of their respective owners.

# **PERFORMANCE SUMMARY** Specifications are at $T_A = 25^{\circ}C$

PARAMETER	CONDITION	MIN	ТҮР	MAX	UNITS
Minimum Input Voltage	I <sub>OUT</sub> = 0A to 0.75A		1.8		V
Maximum Input Voltage	I <sub>OUT</sub> = 0A to 1.5A 5.5				V
V <sub>OUT</sub>	V <sub>IN</sub> = 1.8V to 5.5V, I <sub>OUT</sub> = 0A		12		V ±4%
Output Voltage Ripple	V <sub>IN</sub> = 5V, I <sub>OUT</sub> = 1.5A		100		mV <sub>P-P</sub>
Nominal Switching Frequency			1		MHz



# **QUICK START PROCEDURE**

Demonstration circuit 1859 is easy to set up to evaluate the performance of the LTC3124. For proper measurement equipment setup refer to Figure 1 and follow the procedure below:

NOTE: When measuring the input or output voltage ripple, care must be taken to minimize the length of oscilloscope probe ground lead. Measure the input or output voltage ripple by connecting the probe tip directly across the VIN or VOUT and GND terminals as shown in Figure 2.

- 1. With power off, connect the input power supply to  $V_{\text{IN}}$  and GND.
- 2. Keep the load set to OA or disconnected.

3. Turn the input power source on and slowly increase the input voltage. Be careful not to exceed 5.5V.

NOTE: Make sure that the input voltage  $V_{\text{IN}}$  does not exceed 5.5V.

- 4. Set the input voltage to 5V and check for the proper output voltage of 12V. If there is no output, temporarily disconnect the load to make sure that the load is not set too high.
- 5. Once the proper output voltage is established, adjust the load and observe the output voltage regulation, ripple voltage, efficiency and other parameters.



Figure 1. Proper Measurement Equipment Setup



# **QUICK START PROCEDURE**



Figure 2. Measuring Input or Output Ripple

#### **Changing the Output Voltage**

To change the output voltage from the programmed 12V, change the voltage divider resistors connected to LTC3124 FB pin (see the schematic on page 5).

#### **Converter Output Current**

The DC1859 output current capability depends on the input voltage. Typical performance of DC1859A is shown in Figure 3. As can be seen from Figure 3, the maximum output current is 800mA with 2.6V input and 2A with 5V input. The efficiency is high at light loads thanks to phase shedding in BURST mode. By disabling one phase the related switching losses are reduced and the efficiency is maximized.





#### **Output Load Step Response**

The load step response of DC1859A is dependent on the amount and type of output caps used. If higher load steps need to be handled more output capacitance can be added in order to keep the voltage transients at the desired level. The load step transients are shown in Figure 4. Other types of low ESR and high value capacitors can be used if space is available to reduce load transients to desired level.



Figure 4. The LTC3124 Has Excellent Load Step Response with Small Output Capacitors Thanks to High Switching Frequency and Fast Feedback Loop Compensation

#### Start-Up and Soft-Start Function

The DC1859 features internal 10ms soft-start circuit that prevents input current surge at start-up. The soft-start circuit also prevents output voltage overshoot when output voltage ramp reaches regulation.



# **QUICK START PROCEDURE**



Figure 5. The DC1859 Ramps the Output Slowly at Start-Up without Generating an Input Current Surge

# **PARTS LIST**

### **Output Short Circuit Protection**

The LTC3124 features safe short-circuit and thermal protection. The part can operate continuously with output shorted while maintaining a maximum set current limit. The peak switch current is reduced during overload to about 2A and is restored to 3.5A once the output exceeds 1.5V.

ITEM	QTY	REFERENCE	PART DESCRIPTION	MANUFACTURER/PART NUMBER	
Require	d Circuit	Components			
2	1	C2	CAP, 0805 10µF 10% 10V X5R	MURATA GRM21BR61A106KE19L	
3	1	C3	CAP, 0603 4.7µF 10% 10V X5R	AVX 0603ZD475KAT2A	
4	1	C4	CAP, 0603 0.1µF 10% 25V X7R	AVX 06033C104KAT2A	
5	2	C5, C6	CAP, 1206 22µF 20% 25V X5R	MURATA GRM31CR61E226ME15L	
7	1	C8	CAP, 0805 1µF 20% 16V X5R	AVX 0805YD105MAT2A	
8	1	C9	CAP, 0603 680pF 10% 25V X7R	AVX 06033C681KAT2A	
9	1	C10	CAP, 0603 56pF 5% 50V C0G	AVX 06035A560JAT2A	
12	2	L1, L2	IND, 4.7µH	COILCRAFT XAL6060-472MEC	
14	1	R1	RES, 0603 28k 1% 1/10W	VISHAY CRCW060328K0FKEA	
16	1	R4	RES, 0603 1M 1% 1/10W	VISHAY CRCW06031M00FKEA	
17	1	R5	RES. 0603 110k 1% 1/10W	VISHAY CRCW0603110KFKEA	
18	1	R6	RES, 0603 51.1k 1% 1/10W	VISHAY CRCW060351K1FKEA	
19	2	R8, R9	RES, 0603 1M 5% 1/10W	VISHAY CRCW06031M00JNEA	
20	1	U1	IC, DC/DC CONVERTER	LINEAR TECH. LTC3124EDHC#PBF	
Addition	al Demo	Board Circuit Components			
1	0	C1, C11	CAP. 7343 OPTION	OPTION	
6	0	C7	CAP, 0603 OPTION	OPTION	
15	0	R3, R7	RES, 0603 OPTION	OPTION	
Hardwai	re: For D	emo Board Only			
10	6	E1, E2, E3, E4, E5, E6	TURRET	MILL MAX 2501-2-00-80-00-07-0	
11	2	JP1, JP2	HEADER, 3 PIN SINGLE ROW	SULLINS, NRPN031PAEN-RC	
13	4	MH1, MH2, MH3, MH4	STANDOFF, SNAP ON	KEYSTONE_8831	
21	2	JP1, JP2	SHUNT	SAMTEC 2SN-BK-G	



dc1859afa

# DEMO MANUAL DC1859A

### SCHEMATIC DIAGRAM



Downloaded from Arrow.com.

Information furnished by Linear Technology Corporation is believed to be accurate and reliable. However, no responsibility is assumed for its use. Linear Technology Corporation makes no representation that the interconnection of its circuits as described herein will not infringe on existing patent rights.

DEMO MANUAL DC1859A

#### DEMONSTRATION BOARD IMPORTANT NOTICE

Linear Technology Corporation (LTC) provides the enclosed product(s) under the following AS IS conditions:

This demonstration board (DEMO BOARD) kit being sold or provided by Linear Technology is intended for use for **ENGINEERING DEVELOPMENT OR EVALUATION PURPOSES ONLY** and is not provided by LTC for commercial use. As such, the DEMO BOARD herein may not be complete in terms of required design-, marketing-, and/or manufacturing-related protective considerations, including but not limited to product safety measures typically found in finished commercial goods. As a prototype, this product does not fall within the scope of the European Union directive on electromagnetic compatibility and therefore may or may not meet the technical requirements of the directive, or other regulations.

If this evaluation kit does not meet the specifications recited in the DEMO BOARD manual the kit may be returned within 30 days from the date of delivery for a full refund. THE FOREGOING WARRANTY IS THE EXCLUSIVE WARRANTY MADE BY THE SELLER TO BUYER AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED, IMPLIED, OR STATUTORY, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. EXCEPT TO THE EXTENT OF THIS INDEMNITY, NEITHER PARTY SHALL BE LIABLE TO THE OTHER FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.

The user assumes all responsibility and liability for proper and safe handling of the goods. Further, the user releases LTC from all claims arising from the handling or use of the goods. Due to the open construction of the product, it is the user's responsibility to take any and all appropriate precautions with regard to electrostatic discharge. Also be aware that the products herein may not be regulatory compliant or agency certified (FCC, UL, CE, etc.).

No License is granted under any patent right or other intellectual property whatsoever. LTC assumes no liability for applications assistance, customer product design, software performance, or infringement of patents or any other intellectual property rights of any kind.

LTC currently services a variety of customers for products around the world, and therefore this transaction **is not exclusive**.

**Please read the DEMO BOARD manual prior to handling the product**. Persons handling this product must have electronics training and observe good laboratory practice standards. **Common sense is encouraged**.

This notice contains important safety information about temperatures and voltages. For further safety concerns, please contact a LTC application engineer.

Mailing Address:

Linear Technology 1630 McCarthy Blvd. Milpitas, CA 95035

Copyright © 2004, Linear Technology Corporation



dc1859afa