

Enter keyword, item, model or part #

△ My Account ∨

Ä

PRODUCTS SOLUTIONS TOOLS AND RESOURCES SUPPORT EDUCATION ABOUT ORDER NOW

Overview Documentation



Part Number: EV08L38A

EVB-LAN8670-USB ☆

Download Primary User Guide

- USB to 10BASE-T1S interface card
- Connects to a USB host
- Screw terminal for direct cable connection
- Configurable on-board termination

In Stock: 7 (Processes Immediately)
When can I get more?
Quantity: 1

Buy Now

Overview

The EVB-LAN8670-USB interconnects an USB interface with a 10BASE-T1S Ethernet network interface. The adapter serves as a network card that connects applications via USB 2.0 to the 10BASE-T1S network interface.

System Requirements

System Requirements: USB host; please see documentation section below.

All Application Notes

Documentation

Title 🕏		
EVB-LAN8670-USB PCB Data Package	丛 Download	☆
EVB-LAN8670-USB User's Guide		☆
EVB-LAN8670-USB Linux Driver	<u></u> Download	☆

Silicon Products

Product	Title
LAN8670	10BASE-T1S Single Pair Ethernet PHY
LAN8671	10BASE-T1S Single Pair Ethernet PHY
LAN8672	10BASE-T1S Single Pair Ethernet PHY



Support at Every Step

We are committed to partnering with you and making sure you have what you need to succeed.

Learn About Support

Quick Links Support About MICROCHIP **Microchip Direct** Company Microchip Forums Microchip Technology Inc. Microchip University **AVR Freaks** Careers 2355 West Chandler Blvd. Design Help myMicrochip Contact Us Chandler, Arizona, USA **Technical Support** Media Center Blogs **क़ॗॗॗॗॗॗॗॗॗॗॗॗॗॗॗॗॗॗ क़ॗ** । क़ॗॗॗॗॗॗ