









PR₂ PR₃

Accessories Guide

FlexDock and Charging Options


Docking System	Part Number	Description
	DX2A27700	Two-bay FlexDock, charge only. For the PR2/PR3. No power cord.
	DX2A27710	Two-bay FlexDock, charge only. For the PR2/PR3. North American power cord.
All configurations include dock base, adapter cups, power supply, and are fully assembled. North America configurations include US AC line cord. International configurations require country-specific line cord, ordered separately.		
	DX4A277700	Four-bay FlexDock charge only. For the PR2/PR3. No power cord
	DX4A277710	Four-bay flex dock charge only. For the PR2/PR3. North American Power Cord.
All configurations include dock base, adapter cups, power supply, and are fully assembled. North America configurations include US AC line cord. International configurations require country-specific line cord, ordered separately.		
	DX2A2FF10	4-pos Battery Charger PR2/3 North American Power Cord
	DX2A2FF00	4-pos Battery Charger PR2/3 No Power Cord
All configurations include dock base, adapter cups, power supply, and are fully assembled. North America configurations include US AC line cord. International configurations require country-specific line cord, ordered separately.		
	DX4A2FFF10	8-pos Battery Charger PR2/3 North American Power Cord
	DX4A2FFF00	8-pos Battery Charger PR2/3 No Power Cord
All configurations include dock base, adapter cups, power supply, and are fully assembled. North America configurations include US AC line cord. International configurations require country-specific line cord, ordered separately.		
	203-965-001	FlexDock battery pack charging cup for use with the 4-bay or 2-bay flex dock. PR2 or PR3.
	203-964-001	FlexDock Mobile Printer cup for PR2/3 Mobile printer. For use with the 2-bay or 4-bay flex dock.
	852-916-001	FlexDock Base Quad Charge Only
	852-917-001	FlexDock Base Quad Ethernet
	852-919-001	FlexDock Base Dual Ethernet
	852-920-001	FlexDock Base Desktop

All configurations include dock base, adapter cups, power supply, and are fully assembled. North America configurations include US AC line cord. International configurations require country-specific line cord, ordered separately.




PR₂ PR₃

Accessories Guide



Charging and Power

Accessory Name	Part Number	Description
	318-049-001	Standard Battery Pack, 7.4V 1.62Ah
	318-050-001	Smart Battery Pack PR2/PR3, 7.4V, 1.62Ah
	852-043-004	Cigarette lighter Power Adapter, RoHS
AC Power Cord - 3 Prong	071918 1-974027-025 1-974028-025 1-974029-020 1-974030-025 321-471-002 321-500-002 321-501-002 321-502-002	AC Power Cord, China RoHS AC Power Cord, Europe RoHS AC Power Cord, US RoHS AC Power Cord, UK RoHS AC Power Cord, Australia RoHS AC Power Cord, Italy RoHS AC Power Cord, Japan RoHS AC Power Cord, Denmark RoHS AC Power Cord, India/S Africa RoHS

Belt Clips and Belt Loops

Accessory	Part Number	Description
	825-227-001	Plastic belt clip for the PR2 and PR3.
	825-226-001	Metal belt clip for the PR2 and PR3.
	825-225-001	Belt Loop PR2/3.
	BL-701-102	Vocollect Belt Clip for use with Belt Loop 825-225-001

Protective Cases

Accessory	Part Number	Description
	203-996-001	PR2 Protective Boot.
	203-997-001	PR3 Protective Boot.
	825-222-001	PR2 Protective Case (Environmental case). Ships with shoulder strap.
	825-223-001	PR3 Protective Case (Environmental case). Ships with shoulder strap.

Intermec
by Honeywell

© 2013 Honeywell International Inc.
612186-B 10/13