

Arbitrary Generator Accessory Kit

Nine (9) piece Function/Arbitrary Waveform Generator Kit - Engineer level

Description

The Engineer level function generator kit provides all the necessary cables and adapters to effectively begin using your instrument. These standard interconnects will work with the majority of function and arbitrary waveform generators.

Kit Contains:

- (1) BNC female-male-female Tee Adapter, 50
- (1) BNC female to N male Adapter, 50
- (2) BNC female to 4mm Banana Plug Adapter
- (2) BNC male Cable, RG-58C/U, 50 ,100 cm (40")
- (1) BNC 50 Feed-Thru Terminator, male-female, 2W
- (1) BNC 50 20 dB Attenuator male-female, 4 GHz, 2 W
- (1) BNC male to IC Clips Cable, RG-58C/U, 50 , 100 cm (40")



Technical data subject to change.

© Cal Test Electronics 2018.

caltestelectronics.com

All specifications apply to the unit after a temperature stabilization time of 20 minutes over an ambient temperature range of 25°C ± 5°C.

Specifications

Type	Engineer
Connector Grade	General Purpose
Impedance	50
Temperature (degrees)	0 C to +80 C
RoHS (2011/65/EU)	Compliant

Specifications are subject to change without notice. To ensure the most current version of this manual, please download the current version from our website: caltestelectronics.com

Technical data subject to change.

© Cal Test Electronics 2018.

caltestelectronics.com

