

## FUSE PULLERS & POWR-JAW CLIP CLAMPS



### Features/Benefits

- Ergonomically designed fuse pullers designed to safely remove power fuses
- Molded design offers more comfortable and natural grip than traditional pullers, increasing performance

### Specifications

| TYPE OF FUSE PULLER | PART NUMBER | FUSE SIZE (DIAMETER)                                                                                   |
|---------------------|-------------|--------------------------------------------------------------------------------------------------------|
| Midget Fuse         | MFP         | $\frac{3}{16}$ " - $\frac{1}{2}$ " fuses                                                               |
| Pocket Fuse         | LPFP        | 250 V fuses from 0-200 A<br>600 V fuses from 0-100 A<br>$\frac{9}{16}$ " - $1\frac{19}{32}$ " fuses    |
| Giant Fuse          | GFP         | 250 V fuses from 61-600 A<br>600 V fuses from 61-400 A<br>$1\frac{1}{16}$ " - $2\frac{19}{32}$ " fuses |
| Tri-puller          | 097023      | For ATO and glass fuses                                                                                |

### Web Resources

Sample requests and other technical information:  
[www.littelfuse.com/fusepullers](http://www.littelfuse.com/fusepullers)



### Features/Benefits

- Improve contact between fuse and clip
- Help prevent unnecessary heat from poor contact due to the loss of spring force. This reduces:
  1. Nuisance fuse opening
  2. Premature aging of surrounding components
- High temperature phenolic resin knob for severe environments
- Wide range of coverage with simple design

### Ordering Information

| CATALOG NUMBER | SYSTEM NUMBER | VOLTS      | AMPERES |
|----------------|---------------|------------|---------|
| LCC1           | 0LCC1         | 250        | 0-30    |
| LCC2           | 0LCC2         | 250        | 35-60   |
| LCC2           | 0LCC2         | 600        | 0-30    |
| LCC4           | 0LCC4         | 600        | 35-60   |
| LCC5           | 0LCC5         | 250 or 600 | 70-100  |
| LCC6           | 0LCC6         | 250 or 600 | 110-200 |
| LCC7           | 0LCC7         | 250 or 600 | 225-400 |
| LCC8           | 0LCC8         | 250 or 600 | 450-600 |

*Note: POWR-JAW Clip Clamps are sold individually, not in pairs.  
A minimum of 1/8" of clearance between the fuseblock barrier and fuse clip is required to install Clip Clamps.*

### Web Resources

Sample requests and other technical information:  
[www.littelfuse.com/clipclamps](http://www.littelfuse.com/clipclamps)