

Bazaar

Fusion

Propagate

Community

Wiki

Category

Search for products, brands and platforms


Feedback & Ideas | Help

Bazaar

Ham Radio & Instruments

Accessories for Ham Radio & Instruments


SMA Female to SMA Female Jack Straight Adapter





SMA Female to SMA Female Jack Straight Adapter


SKU 320160011


The Female to Female adapter is required to change the gender of a SMA male cable connector into a SMA female, as well as to provide male-to-male bridge between two cables




















IN STOCK 3 Available

Qty:

-

1

+

ADD TO CART

Description

The Female to Female adapter is required to change the gender of a SMA male cable connector into a SMA female, as well as to provide male-to-male bridge between two cables. This is required when normalizing SMA male connection in RF Explorer Tracking Generator mode.

Features

Female to Female adapter

Easy assembly, no tool required

Specifications


Frequency range: DC ~ 6 GHz

Impedance (Nominal): 50Ω


Datasheet

Questions and Answers

Have a question about this? Ask people who own it.




View History




Basic Bread board - 16.5*5.5 cm

ADD TO CART




Bread board Clear - 8.2 x 5.3cm

ADD TO CART




Mini Bread board 4.5x3.5CM-Blue

ADD TO CART



Mini Bread board 4.5x3.5CM-Black


ADD TO CART




ProtoBoard 9cm * 15cm - 2.0mm

ADD TO CART


Recommendations




SMA M&F 6GHz Semi-Flexible cable...




SMA M&M 6GHz Semi-Flexible cable...




SMA Adapter SMA Plug to SMA Jack...




SMA Termination Male




SMA-BNC adapter SMA Plug to BNC Jack...




50cm length - SMA male to SMA male...




SMA-N adapter SMA Plug to N Jack...




6GHz 2W SMA Attenuator - 30dB




RF Explorer Signal Generator (RFE6GEN)



50cm length - SMA male to SMA female...





Power Limiter






SMA adapter SMA Plug to SMA Jack...






Downloaded from [Arrow.com](#)






	6GHz 2W SMA Attenuator - 10dB
	RF Adapter RP-SMA Jack to SMA Plug...
	RF Explorer Holder
	RF Explorer 6G Combo
	RF Explorer Protection Boot (Blue)
	RF Explorer H-Loop Near Field Antenna...
	RF Explorer Near Field Antenna Kit
	EVA carrying case for 3G Combo

POPULAR SEARCHES

PCB Manufacturing	PCB Stencil	Arduino	XBee	Arduino Shield	Beaglebone Black	Raspberry Pi	Raspberry Pi Touchscreen	LinkIt	Cubieboard	Beaglebone Cape
FPGA	LinkIt ONE	Crazyflie 2.0	Raspberry Pi 3 Model B	RF Explorer	DSO Nano v3	MediaTek X20	HiKey Board	rplidar	raspberry pi relay	RPLIDAR A2

 SHIPPING INFORMATION	 KNOWLEDGE BASE	 HELP CENTER
--	--	---

<p>Seeed Info</p> <p>Reach Us</p> <p>Distributors</p> <p>Designers</p> <p>Careers</p> <p>Site Map</p>	<p>Customer Service</p> <p>Contact Us</p> <p>Customer Support</p> <p>Technical Support</p>	<p>Terms and Conditions</p> <p>Order Information</p> <p>Shipping Information</p> <p>Payment Information</p> <p>Warranty and Return</p> <p>Terms of use</p> <p>Privacy Policy</p>	<p>Stay Tuned</p> <p>Subscribe to get the latest product releases, activities and tutorials from Seeed Studio.</p> <div> <input type="text" value="email address"/> <input type="button" value=" >"/> </div> <div>      </div>
--	---	---	---

Copyright © 2008-2017 Seeed Development Limited All rights reserved	   	Select Language ▼
 Contact Support		