



Sensepal
SENSE PAL
Wireless tagging system for things
To know the condition of an item.

Sensepal
SENSE PAL


You can configure a wireless sensor tag simply by connecting the SENSE PAL expansion module, which is equipped with sensors, to BLUE PAL / RED PAL .

Various SENSE PAL formats are available, and you can choose the PAL format that suits your needs.

Downloaded from Arrow.com.



SENSE PAL List




Opening/closing sensor

OPEN-CLOSE SENSE PAL

Model number: MW-PAL-MAG-0

JAN: 4589512170587

Remarks: Magnet



Environmental Sensor Pal

AMBIENT SENSE PAL


Model number: MW-PAL-AMB-0

JAN: 4589512170594

Notes: Temperature, humidity, illuminance

Downloaded from Arrow.com.

PAL ›



Motion sensor pal

MOTION SENSE PAL

Model number: MW-PAL-MOT-0

JAN: 4589512170600

Remarks: Acceleration

Motion sensor PAL ›

table of contents


1 To make it happen

2 System Configuration Example

3 Instructions for use

4 SENSE PAL List

Downloaded from Arrow.com.




To know the condition of an item.

You can remotely monitor the status of objects from a distance.


Sensors can be attached to objects to collect data wirelessly.

System Configuration Example

Downloaded from Arrow.com.




Instructions for use



STEP 1
Install the BLUE/RED PAL.


Connect the BLUE/RED PAL and SENSE PAL. Pay attention to the orientation and make sure they are securely connected all the way in.



STEP 2
Insert the batteries.

Insert the CR2032 coin-type lithium battery into the battery holder. Pay attention to the orientation and push it firmly all the way in.


Downloaded from Arrow.com.



STEP 3
Prepare the main unit.

1. Connect the MONOSTICK to your computer and write the master unit application to the MONOSTICK.
2. Launch the display software on your computer.

Prepare the main unit. ›



Ready!
Start using.

Sensor data is collected wirelessly and displayed on a computer screen. This allows you to monitor the status of various objects.

retailers

Monowireless products can be purchased at physical stores or online.

‹ BLUE PAL / RED PAL 前

次 PAL CONTROL ›

Downloaded from Arrow.com.