RK14K1220A5V 14mm Size Insulated Shaft Snap-in Type RK14K Series

Discontinued

Obsolete

Standard

In Use

Basic Information

In Stock

Number of resistor elements	Dual-unit
Control part orientation	Vertical
Bushing	With
Shaft types	Flat
Length of the shaft (dF)	12.5mm
Detent	Without
Total resistance	10kΩ
Resistance taper	10A
Dimensions	14mm size

Specifications

Operating temperature range		-10°C to +70°C
Electrical performance	Total resistance tolerance	±20%
	Rated power	0.05W
	Maximum operating voltage	50V AC/ DC only
	Gang error	±6dB to 0dB 5dB max.
	Insulation resistance	100MΩ min. 250V DC
	Voltage proof	300V AC for 1 minute
Mechanical performance	Rotational torque	30 to 200mN·m
	Rotational torque range	0.3N·m
	Stopper strength	0.5N·m
	Stopper strength	80N max.
	Vibration	10 to 55 to 10Hz/min., the amplitude is 1.5mm for all the X, Y and Z axes (The duration of X, Y and Z are For 2 hours respectively
Durability	Operating life	15,000 cycles
Minimum order unit(pcs.)	Japan	1,000
	Export	2,000

Dimensions



Zoom an unavailable image in a separate window

Mounting Hole Dimensions

Zoom an unavailable image in a separate window

Terminal Layout / Circuit Diagram

Zoom an unavailable image in a separate window

Packing Specifications

Tray

Number of packages (pcs.)	
1 case / japan	1,000
1 case / export packing	2,000

Export package measurements (mm)
540×375×265

Soldering Conditions

Reference for Hand Soldering

Tip temperature
350°C max.

Soldering time
3s max.

No. of solders
1 time

Notes are common to this series/models

1. This mix-tuning shows only routine specifications. When using the products, please obtain formal specifications for supply.
2. Specifications listed above are minimum order unit (integer).
3. Products other than those listed in above products are also available. Please contact us for details.
4. Test and weather are not checked. Please specify if required.

Cautions

Recommended Circuit Configuration

Please use the potentiometer in the voltage adjustment circuit (Fig. A). Avoid using it in the current adjustment circuit (Fig. B) as it is affected by the contact resistance variations it causes when used as the variable resistor.



Direct Voltage

When direct voltage is flown through this part, terminal's terminal insulation may deteriorate depending on the use environment. This is due to migration phenomenon. Contact us if you are planning to use this part under direct voltage.

Impedance on the Output Side

There is a possibility that might be affected by contact resistance of resistive element and wiper in case of low impedance of output side in voltage regulation circuit. For this reason, we require that you adjust to impedance of output side more than 100 times of total resistance.

Residual Resistance

Although electric poles of resistors are generally formed by silver printing, we provide carbon coating over the silver poles to enhance reliability against sulfurization. Contact us if you wish to use the part in a low-residual-resistance state.

Dew Condensation

Avoid using the potentiometer where dew or water drops might occur on the surface of the resistor, etc. Deterioration of insulation or shorting may occur.

Soldering

To avoid potential contact issues, please do not solder wires to the top surface of the printed circuit board as shown in the diagram. Solder all metal lugs into a substrate before use.



Stress Being Applied to the Terminals

Always pay special attention not to apply excessive stress when handling the terminals. Also, be sure to design appropriate soldering conditions.

Looseness of the Shaft

When lengths shaft lengths are being changed, the looseness (deviation) tends to grow in proportion to the shaft length. Conducting a test under actual operating conditions is recommended.

Chassis Mounting

The use of a nut to fasten this part may lead to excessive tightening and can deteriorate the rotary correct performance, or strip the threads. Handle with care when tightening the nut.

Use of Cleaning Liquid

Since synthetic resins such as polycarbonate are being used as the material for the insulated type shafts, avoid using this part under epoxy resin cleaning liquid, trichloroethylene, trichloroethane, gasoline, alcohols, aromatic hydrocarbons, ketones, esters and halogenated hydrocarbons, especially under their immersion gas environment.

Operation at Low Temperature

When these products are expected to be used under low temperature environments such as applications for car radios and car stereos, we will provide you with the lowest temperature specifications available. When placing orders, indicate whether the low temperature specifications are necessary or not.

Storage

1. *Store the products as delivered, at a normal temperature and humidity, without direct sunshine and corrosive gas ambient. Use them at specified possible storing, not later than six months upon receipt.*
2. *After finishing the test, keep the products in a plastic bag so that can ambient air, store them in the same environment as above, and use them up as soon as possible.*
3. *Do not store in too many switches.*

The above operation notes are quoted from the "Production and Guideline of Electronic Parts for Industrial Devices", which is a technical report issued by the Japan Electronics and Information Technology Industries Association (EIAJ RC-2131A in March 2002). For details, see the above-mentioned report.

Measurement and Test Methods

Electrical performance

Total Resistance

With the shaft (lever) placed at the termination of terminal 1 or 3, total resistance shall be determined by measuring the resistance between the resistor terminals 1 and 3 unless otherwise specified.

Rated Power

Rated power shall be the maximum value of electric power that can be applied continuously to the whole area of a resistor (between terminals 1 and 3) at the rated ambient temperature.

The rated ambient temperature of a carbon film resistor shall be 50°C. The maximum power at an ambient temperature of 50 to 70°C shall be obtained by multiplying the power by the rated power ratio determined from the derating curve shown below.



Rated Voltage

Rated voltage is associated with the rated power and shall be determined by the following equation. When the resulting rated voltage exceeds the maximum operating voltage of a specific resistor, the maximum operating voltage shall be taken as the rated voltage.

$$E = \sqrt{P \times R}$$

E : rated voltage (V)
P : rated power (W)
R : total nominal resistance (Ω)

Tap Resistance

Determined by measuring the resistance between a tap terminal and a specified terminal (terminal 1 or terminal 3).

Residual Resistance

With the shaft (lever) placed at the terminal of terminal 1, the residual resistance shall be measured between the terminals 1 and 2. Next, with the shaft (lever) placed at the terminal of terminal 3, the residual resistance shall be measured between the terminals 2 and 3. Unless otherwise specified, the shaft (lever) shall be positioned and the resulting minimum resistance between the tap terminal and the terminal 2 shall be measured.

Maximum Attenuation Level

With the shaft placed at the terminal of terminal 1, maximum attenuation level shall be determined by measuring the voltage applied between the terminals 1 and 2 and calculating the ratio to the voltage applied between the terminals 1 and 3.
Unless otherwise specified, the value obtained shall be considered as the residual resistance of a rotary potentiometer for volume control.

Insertion Loss

With the shaft placed at the termination of terminal 3, insertion loss shall be determined by measuring the voltage applied between the terminals 1 and 2 and calculating the ratio to the voltage applied between the terminals 1 and 3.
Unless otherwise specified, its value is usually used in place of the residual resistance of a rotary potentiometer for volume control.

Sliding Noise

When rotating by connecting the resistor to an amplifier having frequency characteristics specified in JIS C 5401, applying DC voltage of 2fV between the terminals 1 and 3 (if rated voltage is 20V or less, this voltage shall be applied) and by rotating (moving) the shaft (lever) at a speed of about 30 cycles per minute.

Voltage Withstand

Voltage withstand applying AC voltage to the specified locations for one minute to checking for any arc, burning, dielectric breakdown and other abnormalities. Respective terminals may be tested together. The locations described below shall be tested unless otherwise specified. However, if the section concerned is so constructed as to conduct, that particular part shall not be tested.

Insulation Resistance

Measured with a megger by applying specified voltage to the specified locations.
The locations below shall be tested unless otherwise specified. However, if the section concerned is so constructed as to conduct, that particular part shall not be tested.

Measuring Locations For Withstand Voltage and Insulation Resistance

- *Between terminal and shaft (lever).*
- *Between terminal and metal cover (frame).*
- *Between terminals connected to separate resistor elements and terminal connected to another resistor elements (if multi-gang unit).*
- *Between switch terminal and shaft (lever).*
- *Between switch terminal and resistance terminal.*
- *Between switch terminal and metal cover.*

Gang Error

With the shaft (lever) placed in the specified position, gang error shall be determined by applying test voltage of 2 to 10V (sine-wave RMS value) between the terminals 1 and 3 of each unit. Then, gang error between the measuring the voltage between the terminal 2 and the specified terminal (terminal 1 or 3) and then by using the following equation.

$$\text{Gang error} = 20\log\frac{V_2}{V_1}$$

Where,
V1 : Voltage between the reference resistor terminals 1 and 2 (voltage between the terminals 2 and 3 if the resistance tapers are C, T and reverse D)
V2 : Voltage between the non-reference resistor terminals 1 and 2 (voltage between the terminals 2 and 3 if the resistance tapers are C, T and reverse D)
In the case of tap terminal, measurement shall be made by connecting a fixed resistor whose resistance is equivalent to 1/10 of the nominal total resistance between the tap terminal and the terminal 1 of the resistance taper in C, make connection between.

Contact Resistance of Switch

Unless otherwise specified, resistance resistance of switch shall be determined by measuring drop voltage when 5V DC, 1A is applied between contacts and the contacts are closed.

Mechanical Performance

Total Rotational Angle (Travel)

Determined by measuring the rotational angle (travel) when the shaft (lever) is turned (moved) from the termination position of terminal 1 to the termination position of terminal 3.

Rotational Torque (Operating Force)

Determined by measuring the torque (operating force) necessary to turn (move) the shaft (lever). Unless otherwise specified, measurement shall be made at an ambient temperature of 5 to 35°C, and the shaft rotational speed shall be 60° per second and the lever moving speed 30mm per second.

Starting Torque (Starting Force)

Determined by measuring a torque (operating force) necessary to turn (move) the shaft (lever) for the first time after allowing the test piece to stand for a long period of time unless otherwise specified. Measurement shall be made at an ambient temperature of 5 to 35°C, and the shaft rotational speed shall be 60° per second and the lever moving speed 30mm per second.

Stopper Strength

To be specified only when required in particular.

Shaft Wobble

Determined by measuring the amount of deflection at a position of 20mm from the reference surface with a bending moment of 0.19N·m applied perpendicularly to the shaft (lever) in the direction of shaft from 180° different directions at the free end. Unless otherwise specified, the value where a smooth cylindrical surface of the shaft causes is zero. However, if the length of the shaft is less than 20mm, proportional calculation shall be used.

Allowable Operating Torque for Shaft (Lever)

With the shaft (lever) placed at the termination of terminal 1, a specified torsional moment (torque) shall be applied in that direction for 10 seconds. Next, with the shaft (lever) placed at the termination of terminal 3 and a specified torsional moment (torque) shall be applied similarly. Unless otherwise specified, its value shall be used as the rotation sections for any deformation or breakage.

Push-pull Strength/ Lever Push-pull Strength

A specified force shall be applied in the axial direction of the shaft (lever) for 10 seconds to check the control part and other sections for any deformation or breakage and for operating condition.

Resistance Taper

Resistance Taper

With the shaft (lever) placed at the specified position, resistance taper shall be determined by measuring the voltage between the specified terminals (terminal 1 and 2, or between terminals 2 and 3)and calculating the percentage in reference to the voltage between terminals 1 and 3.
Reference: Standard resistance tapers in reference to rotational angles (travels) are as shown below.



Inquiries about Products

Category List

Sensors
Semiconductors
TACT Switch™
Switches
Encoders
Potentiometers
Connectors →
Wireless Communication Devices
Multi Control Devices
Aspherical Glass Lenses
Actuators →
Haptic Inactor →
Capacitive Sensing Modules →

© 2024 ALPS ALPINE CO., LTD.