


Piezo Haptic Element

Product No. 034340

BPH1204T138MW100 HF

Issue No. BS/TEY01.1246



Features:

- High reliability
- High sensitivity
- Less power consumption
- Temperature performance
- **RoHS**


BESTAR Sensortech Co., Ltd. www.bestarsensor.com | feng.gao@bestarsensor.com

Release Version:A



Content:

1 Characteristics	 3
1.1 Technical terms	 3
1.2 Test method	 4
2 Part List	
3 Dimension	
4 Reliability Test	 8
5 Packing	 9
5.1 Packing drawing	 9
5.2 Packing quantity	 .9
6 History change record	 .10
7 Important Notice	11



1.Characteristics

1.1Technical terms

Downloaded from Arrow.com.

420±20% nF
5~10g(peak)
2~4g(peak)
>280 °C
>450 pC/N
38±0.5KHz
-10+60 V
Ag
Ink pot
PZT 5
0.6g
-40+85℃
-40+125℃

Mary Assessor Myssolffun

1.2 Test method:

1.2.1 Resonant Frequency

Piezoelectric should be hung vertically downwards from the electrical connection and measure its frequency by using impedance analyzer at room temperature.

Input frequency shall be swept within 30-45kHz and the step size is less than 50 Hz, where the resonant frequency is defined.

1.2.2 Capacitance

A electrostatic capacity capacitance shall be measured at 1KHz by using LCR meter, such as DF2812A LCR numerical bridge or equivalent. The part shall be clamped in the same way as the measurement of resonant frequency mentioned in section 1.2.1.

1.2.3 Positive Test


The positive test should be measured by using d33 quasi static instrument. The part shall be clamped on the vibrating table frock. The positive mark side is up.


Parts shall be measured under a condition(Temperature:+15°C to +30°C,Humidity:60 to 90% R.H.) unless the standard condition(Temperature:+25±3°C,Humidity:60±10%R.H.) is redulated to measure.

PZT




1.2.4 Acceleration test






2.Part List





- 3. sheetmetal
- 2. PZT
- 1. sheetmetal

Release Version:A Page 06 of 11 BESTAR SENSOR



3. Dimension





4. Reliability test


4.1High temperature test

Temperature $+85^{\circ}$ C Duration 240hrs

4.2 Low temperature test


Temperature -40° C Duration 240hrs

4.3 Temperature cycle test



4.4 Humidity cycle test

Cycles 5



4.5 Accelerated Life Test (ALT)

Temperature 200°C

Duration 2hrs

4.6 Vibration Test

Vibration Frequency 10-55Hz

Amplitude 1.5mm

Duration x,y&z directions 30min

4.7 Solderability test

Release Version:A

Downloaded from Arrow.com.

Solderability temperature $245\pm5^{\circ}$ C

Heat applying time 3±0.5sec

All test should be carried out after 24 hours when


the PZT picked up from the experiment box.

All specifications must be satisfied in this condition.



Page 08 of 11

BESTAR SENSOR



5. Packing


5.1 Packing drawing (unit:mm)



5.2. Packing quantity

Release Version:A

Downloaded from Arrow.com.



Quantity: 20 Plastic case /Box 2000 PCS/Box(390*250*170mm)

BESTAR SENSOR



6. History change record

Version	Change Items	Date	Drawn	Checked	Approved
А	First Edition	2021.07.22	Caishuqi	Qiujun	Gaofeng
	/9	06			



7.Important Notice

7.1 The products mustn't be washed

7.2 Store Condition (packing)

The products should be stored in the room ,where the temperature/humidity is stable. And avoid suchplaces where there are large temperature changes. Please store the products at the following conditions:

Temperature: $-30 \text{ to} + 85^{\circ}\text{C}$ Humidity: 15 to 85% R.H.

7.3 Expire Date on Storage

Expire date (Shelf life) of the products is twelve months after deliveried under the conditions of a sealed and an unopened package. Please use the products within twelth months after deliveried.

7.4 Notice on Product Storage

- (1) Please do not store the products in a chemical atmosphere (Acids, Alkali, Bases, Organic gas, Sulfides and so on), because the characteristics may be reduced at quality, and/or be degraded in the solderability due to the storage in a chemical atmosphere.
- (2) Please use the products immediately after the package is opened, because the characteristics may be reduced at quality, and/or be degraded in the electrode pull-off force due to storage under the poor condition.

7.5 Notice on Transfer

PZT is fragile. Please be careful when transfer. Keep the PZT away from the damage



Release Version:A Page 11 of 11 BESTAR SENSOR