QUICK START GUIDE FOR DEMONSTRATION CIRCUIT 747 LOG-LINEAR RF/IF DETECTOR

LT5537

DESCRIPTION

Demonstration circuit 747 is a log-linear RF/IF detector featuring the LT®5537.

The LT5537 is a wide dynamic range RF/IF log detector, operational from below 10MHz to 1000MHz. The lower limit of the operating frequency range can be extended to near DC by the use of an external capacitor. The input dynamic range at 200MHz with ±3dB nonlinearity is 90dB (from -76dBm to 14dBm, single-

ended 50Ω input). The detector output voltage slope is normally 20mV/dB, and the typical temperature coefficient is 0.01dB/°C at 200MHz.

Design files for this circuit board are available. Call the LTC factory.

LTC is a trademark of Linear Technology Corporation

Table 1. Typical Performance Summary ($V_{CC} = 3V$, ENBL = 3V, $T_A = 25$ °C, unless otherwise noted. Test circuit shown in Figure 1.)

PARAMETER	CONDITION	VALUE
Supply Voltage		2.7V to 5.25V
Supply Current		13.5mA
Shutdown Current	ENBL = Low	500μΑ
ENBL Voltage	Low, Chip Disabled	0.3V max
	High, Chip Enabled	1.0V min
ENBL Input Current	V _{ENBL} = 0V	0μΑ
	V _{ENBL} = 3V	100μΑ
RF/IF Input DC Common Mode Voltage		(V _{CC} - 0.4) V
Small-Signal Impedance	Measured at 200MHz	1.73kΩ // 1.45pF
Output Start Voltage	No Input Signal Present	0.4V
Response Time	Input from –30dBm to 0dBm, C _{LOAD} = 2.5pF	110ns
Baseband Modulation Bandwidth	Output Load Capacitance = 2.5pF	6MHz
Input Frequency Range	Operation at lower frequency is possible. See LT5537 datasheet.	10MHz to 1GHz
Maximum Input Power for Monotonic Output	50Ω Termination	
	200MHz	14.0dBm
	600MHz	11.6dBm
	1GHz	9.4dBm
f = 10MHz		
Linear Dynamic Range	±3dB Error	88.8dB
	±1dB Error	72.5dB
Slope	R1 = 33k (The output slope is adjustable using R1.)	19.6mV/dB
Intercept	V _{OUT} = 0V, extrapolated	-97dBm
Sensitivity	Sensitivity can be improved by as much as 10dB by using a narrow-band input matching network. See LT5537 datasheet.	-76.7dBm
Temperature Coefficient	P _{IN} = -20dBm	-0.007dB/°C

QUICK START GUIDE FOR DEMONSTRATION CIRCUIT 747 LOG-LINEAR RF/IF DETECTOR

f = 100MHz			
Linear Dynamic Range	±3dB Error	90.5dB	
	±1dB Error	82.8dB	
Slope	R1 = 33k (The output slope is adjustable using R1.)	20.3mV/dB	
Intercept	V _{OUT} = 0V, extrapolated	-95dBm	
Sensitivity	Sensitivity can be improved by as much as 10dB by using a narrow-band input matching network. See LT5537 datasheet.	-77dBm	
Temperature Coefficient	P _{IN} = -20dBm	-0.004dB/°C	
f = 200MHz			
Linear Dynamic Range	±3dB Error	90.3dB	
	±1dB Error	83.5dB	
Slope	R1 = 33k (The output slope is adjustable using R1.)	21.2mV/dB	
Intercept	V _{OUT} = 0V, extrapolated	-94dBm	
Sensitivity	Sensitivity can be improved by as much as 10dB by using a narrow-band input matching network. See LT5537 datasheet.	-76.4dBm	
Temperature Coefficient	P _{IN} = -20dBm	0.010dB/°C	
f = 400MHz			
Linear Dynamic Range	±3dB Error	88.2dB	
	±1dB Error	70.8dB	
Slope	R1 = 33k (The output slope is adjustable using R1.)	23.1mV/dB	
Intercept	V _{OUT} = 0V, extrapolated	-91dBm	
Sensitivity	Sensitivity can be improved by as much as 10dB by using a narrow-band input matching network. See LT5537 datasheet.	-75.3dBm	
Temperature Coefficient	P _{IN} = -20dBm	0.019dB/°C	
f = 600MHz			
Linear Dynamic Range	±3dB Error	85.8dB	
	±1dB Error	72.5dB	
Slope	R1 = 33k (The output slope is adjustable using R1.)	25.2mV/dB	
Intercept	V _{OUT} = 0V, extrapolated	-89dBm	
Sensitivity	Sensitivity can be improved by as much as 10dB by using a narrow-band input matching network. See LT5537 datasheet.	-74.1dBm	
Temperature Coefficient	P _{IN} = -20dBm	0.026dB/°C	
f = 1GHz			
Linear Dynamic Range	±3dB Error	63.5dB	
	±1dB Error	51.7dB	
Slope	R1 = 33k (The output slope is adjustable using R1.)	31.4mV/dB	
Intercept	V _{OUT} = 0V, extrapolated	-80dBm	
Sensitivity	Sensitivity can be improved by as much as 10dB by using a narrow-band input matching network. See LT5537 datasheet.	-69.2dBm	
Temperature Coefficient	P _{IN} = -20dBm	0.031dB/°C	



QUICK START PROCEDURE

Demonstration circuit 747 is easy to set up to evaluate the performance of the LT5537. Refer to Figure 1 for proper measurement equipment setup and follow the procedure below:

- 1. Connect voltmeter's negative (-) lead to demo board GND test point (E4 or E5).
- 2. Connect voltmeter's positive (+) lead to the demo board OUTPUT test point (E2).
- 3. Connect DC power supply's negative (-) output to demo board GND test point (E4 or E5).
- 4. Connect DC power supply's positive (+) output (2.7V to 5.25V) to demo board V_{CC} test point (E3).
 - **NOTE**: Do not exceed 5.5V, the absolute maximum supply voltage.

- Connect signal generator's output to demo board INPUT port (SMA connector J1) via coaxial cable.
 A 3dB attenuator may be inserted to improve input match.
- **6.** Using a jumper cable, connect demo board V_{CC} test point (E3) to ENBL test point (E1). Now the detector is enabled (on) and is ready for measurement.

NOTE: Make sure that the power is not applied to ENBL before it is applied to V_{CC} . The voltages on the ENBL test point must never exceed $V_{CC} + 0.2V$.

7. Apply RF input signal and measure OUTPUT DC voltages.

NOTE: Do not exceed +22dBm, the absolute maximum RF input power.




Figure 1. Proper Measurement Equipment Setup



QUICK START GUIDE FOR DEMONSTRATION CIRCUIT 747 LOG-LINEAR RF/IF DETECTOR

