



# SIGNAL CONDITIONER

# LVDT/RVDT MACRO EAZY-CAL™ LVC-4000

## Overview

The EAZY-CAL™ LVC-4000 is a standalone signal conditioner, supporting a wide range of AC LVDTs, RVDTs, and VR half-bridges, while providing several choices of voltage, current, and digital RS-485 outputs. Push-button calibration offers intuitive operation as compared to signal conditioners with span and offset trim pots. Fault conditions, such as a wire break on LVDT/RVDT connections, are indicated by blinking LEDs, fault condition error output, and Error Flag Open Collector signal (see manual for details). The LVC-4000 operates from a 9-30V DC power supply and is housed in a polyamide DIN railmounted enclosure. Calibration instructions, terminal functions, LVDT connection diagram and DIP switch functions are printed on the side panels for convenience.

Synchronization to other signal conditioners is accomplished by a daisy chain connection to a synchronization bus. One unit will assume the Master function based on DIP switch priority setting. If a fault should occur, the next highest priority unit will take over as Master.

With the use of the RS-485 port, a host computer is able to retrieve measurement data, receive operational status, perform remote calibration, and perform hot swap reconfiguration.

### **Features**

- Push-button or RS-485 command auto-calibration
- Analog voltage or current loop output
- ◆ Digital RS-485 interface
- Supports standard AC LVDTs, RVDTs, and VR half-bridge sensors
- Master/slave excitation synchronization
- ◆ DIN-rail mountable
- Color-coded terminal blocks

### **User Selectable Features**

- 0-5V DC, 0-10V DC, 0.5-4.5V DC,  $\pm$ 5V DC,  $\pm$ 10V DC or 4-20 mA output
- ◆ 1.5V<sub>rms</sub> or 3.0V<sub>rms</sub> sensor excitation
- ◆ 2.5, 5, 7.5, or 10 kHz excitation frequency

### **Environmental Data**

| Operating |  |
|-----------|--|
|-----------|--|

**Temperature** 

-20 to 75°C (0 to 165°F)

Temperature

Sensitivity

<0.02% of FSO/°C (<0.01% of FSO/°F)

**EMC Compliance** Emissions: EN55011:2007

Immunity: EN61000-4-2:2009

EN61000-4-4:2004


EN61000-4-6:2009


EN61000-4-3:2010+A2:2010


### **Electrical Data**

| Power Input                    | 9-30V DC (90 mA max. @ 24V DC)  | Output Non-Linearity         | ≤±0.1% full scale output  |
|--------------------------------|---|------------------------------|---|
| Sensor Excitation              | 3.0V <sub>rms</sub> (1.5V <sub>rms</sub> selectable)  | Output Voltage Ripple        | 1 mV <sub>rms</sub> max. (2.5 kHz excitation, no filter)<br>2 mV <sub>rms</sub> max. (10 kHz excitation, no filter) |
| Sensor Excitation<br>Frequency | 2.5 kHz, 5 kHz, 7.5 kHz, or 10 kHz  |                              |   |
| Input Sensitivity<br>Range     | 55 mV <sub>rms</sub> to 5.5 V <sub>rms</sub> full scale input produces full scale DC output | Output Current Ripple        | 10 μA <sub>rms</sub> max. (2.5 kHz excitation, no filter) 20 μA <sub>rms</sub> max. (10 kHz excitation, no filter)  |
| Full Scale Outputs             | 0-5V DC, 0-10V DC, 0.5-<br>4.5V DC, ±5V DC, ±10V<br>DC or 4-20 mA output                    | Frequency Response<br>(-3dB) | 500 Hz max.   |

## Connection Diagrams







#### **NORTH AMERICA**

Measurement Specialties, Inc., a TE Connectivity Company Phone +1-800-522-6752 Email: customercare.pens@te.com

#### TE.com/sensorsolutions

Measurement Specialties, Inc., a TE Connectivity company.

Accustar, American Sensor Technologies, AST, ATEXIS, DEUTSCH, IdentiCal, TruBlue, KPSI, Krystal Bond, Microfused, UltraStable, Measurement Specialties, MEAS, Schaevitz, TE Connectivity, TE, and the TE connectivity (logo) are trademarks of the TE Connectivity Ltd. family of companies. Other logos, product and company names mentioned herein may be trademarks of their respective owners.

The information given herein, including drawings, illustrations and schematics which are intended for illustration purposes only, is believed to be reliable. However, TE Connectivity makes no warranties as to its accuracy or completeness and disclaims any liability in connection with its use. TE Connectivity's obligations shall only be as set forth in TE Connectivity's Standard Terms and Conditions of Sale for this product and in no case will TE Connectivity be liable for any incidental, indirect or consequential damages arising out of the sale, resale, use or misuse of the product. Users of TE Connectivity products should make their own evaluation to determine the suitability of each such product for the specific application.

