
QI Standard A6 Triple Transmit Wireless Charge Coil

Pulse Part Number WMRT399A-0

V03

Features



- Meet the QI international standard
- Antifreeze film of transmitter is injection molding, make use of V-ON material, unzerbrechlich, breakage proof, every shape suitable
- Length and gap of the outgoing line is customizability



Application

-Mobile phone wireless charge



QI Standard A6 Triple Transmit Wireless Charge Coil

Pulse Part Number WMRT399A-0

V03

Electrical specifications

Standard Voltage(V)	5/12V
Max Current (A)	2A
DC Resistance (mΩ)	80±10%
Inductance(uH)	Top:11.5+/-10% Bottom:12.5+/-10%
Rs $(m\Omega)$	90-110
Q	>70
Wire Diameter (mm)	0.08*105 strands cotton-insulated wire
Testing Environment	100KHZ/1V




QI Standard A6 Triple Transmit Wireless Charge Coil

Pulse Part Number WMRT399A-0

V03

Mechanical dimensions: mm



WINDING DETAILS

Wdy.N O. 绕组	Star 开始	Finis h 结束	Tur ns 圈 数	Wire Diameter 线径	Wdg.TyepeSprad /lose 绕线方法疏/密 绕	Wdg.Directio n 绕线方向	Turns/Layer 层数/每层圈数
	S	T	12T S	0.08*105 strand s cotton- insulated wire	1 Layer lose	anticlockwise	1 layer/ 12TS

Contact: mobiledeviceantenna.sales@pulseelectronics.com



QI Standard A6 Triple Transmit Wireless Charge Coil

Pulse Part Number WMRT399A-0

V03

Packing


- ➤ Put 1pcs product in the poly bag, then add the info label.
- ➤ Align the finished goods into the tray.
- ➤ Cardboard sheet under and on the top of the tray stack in the tray stack. Every second tray must be rotated 180 degrees, binding of the stack-1 strap lengthwise and 2 stray crosswise.
- Add foam paper between two trays.
- First put down 1pcs sheet board in box, then put binding tray in box, empty 1 pcs on the top of the box.
- ➤ Binding of the carton: scaled with tape, 1 strap length wise and 2 strap crosswise.



Label content:

P/N:
Project Name:
Inductance:

- --P/N, e.g. SWA1380
- --Project Name, e.g. A6 Wireless Charge Coil
- --Inductance, e.g. 12.5uH





Contact: mobiledeviceantenna.sales@pulseelectronics.com