

MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918 Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com

RS232 Isolator Click



PID: MIKROE-2864

RS232 Isolator click is a fully isolated dual transceiver click, used to provide secure and easy UART to RS232 conversion, with the galvanic isolation. The digital input and output signals are transmitted across the isolation barrier by utilizing the Analog Devices proprietary iCoupler® technology - IC scale transformer windings couple the digital signals magnetically, from one side of the barrier to the other, providing the galvanic isolation and transfer rates up to 460Kbps.

RS232 Isolator click can be used for galvanic isolation of RS232 signals, whenever there is a need for that kind of isolation - operating in harsh environments where electrostatic discharges (ESD) can occur, when the RS232 cable is plugged in and out frequently, and generally - wherever the sensitive part of the RS232 controller logic circuitry needs to be protected.

RS232 Isolator click is a fully isolated dual transceiver click, used to provide secure and easy UART to RS232 conversion, with the galvanic isolation. The digital input and output signals are transmitted across the isolation barrier by utilizing the Analog Devices proprietary iCoupler® technology - IC scale transformer windings couple the digital signals magnetically, from one side of the barrier to the other, providing the galvanic isolation and transfer rates up to 460Kbps.

RS232 Isolator click can be used for galvanic isolation of RS232 signals, whenever there is a need for that kind of isolation - operating in harsh environments where electrostatic discharges (ESD) can occur, when the RS232 cable is plugged in and out frequently, and generally - wherever the sensitive part of the RS232 controller logic circuitry needs to be protected.

Mikroe produces entire development toolchains for all major microcontroller architectures.

Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.



ISO 27001: 2013 certification of informational security management system. ISO 14001: 2015 certification of environmental management system. OHSAS 18001: 2008 certification of occupational health and safety management system.



ISO 9001: 2015 certification of quality management system (QMS).



MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918 Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com


How does it work?

The RS232 is a serial communication standard, which was first introduced in '60s. It became very popular during '90s, as it became an integral part of many PC motherboards. After several reviews of this standard and thanks to its simplicity and past ubiquity, RS232 is still being used - particularly in industrial machines, networking equipment, and scientific instruments where a short-range, point-to-point, low-speed wired data connection is required.

www.mikroe.com

The logic voltage levels used by the RS232 can go up to $\pm 15V$ with respect to the common ground. This is very different than the CMOS/TTL voltage levels used on many MCUs and other types of commonly used modern devices, so the first task of the RS232 isolator board is to provide appropriate RS232/TTL levels.

The main active component of the RS232 Isolator click is the <u>ADM3252E</u>, an integrated dual-channel RS232 driver/receiver, with the iCoupler® isolation technology, made by <u>Analog Devices</u>. This integrated circuit features four integrated galvanic isolation elements that provide the required isolation level. RS232 level inputs are inverted and encoded into waveforms that are used to energize the primary windings of the integrated transformers. At the secondary windings, the induced waveforms are decoded back into the digital values and routed to the pins, with the appropriate TTL/CMOS voltage levels. The same working principle is applied in the opposite direction, too. This way, the digital signals are effectively conducted through the isolation barrier.



Besides the UART RX and TX lines, the click also supports the hardware flow control via the CTS and RTS lines. One of the two existing channels is used for the UART data communication itself, while the other channel is used for the hardware flow control lines. The usage of the control lines is not always mandatory, so the lines can be disconnected from the mikroBUS if needed, by unsoldering the SMD jumpers labeled as J1 and J2.

The ADM3252E IC also features the isoPower^{\dagger} technology - an integrated DC-DC converter for generating all the required voltage levels, making it possible to power the click board † by 3.3V or 5V. The operating voltage for the click board † can be set with the onboard SMD jumper.

Mikroe produces entire development toolchains for all major microcontroller architectures.

Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.



ISO 27001: 2013 certification of informational security management system.
ISO 14001: 2015 certification of environmental management system.
OHSAS 18001: 2008 certification of occupational health and safety management system.



MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918

Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com

www.mikroe.com

RS232 Isolator click features the onboard D-Sub 9 (DE9) connector for an easy and secure connection.

Specifications

Туре	Isolators,RS232
Applications	For applications which operate in harsh, industrial environments, when the RS23 cable is plugged in and out frequently. It can be used whenever the sensitive control circuitry needs to be isolated from the RS232 line levels.
On-board modules	ADM3252E, an isolated, dual channel, RS-232 line driver/receiver from Analog Devices
Key Features	High voltage galvanic isolation of RS232 lines, high speed communication, up to 460 Kbps, D-Sub connector for easy connection
Interface	GPIO,UART
Feature	No ClickID
Compatibility	mikroBUS™
Click board size	L (57.15 x 25.4 mm)
Input Voltage	3.3V or 5V

Pinout diagram

This table shows how the pinout on RS232 Isolator click corresponds to the pinout on the mikroBUS™ socket (the latter shown in the two middle columns).

Notes	Pin	nikro™ BUS		Pin	Notes		
	NC	1	AN	PWM	16	NC	
	NC	2	RST	INT	15	RTS	Request to Send
Clear to Send	CTS	3	CS	RX	14	TXD	Transmit Data
	NC	4	SCK	TX	13	RXD	Receive Data
	NC	5	MISO	SCL	12	NC	
	NC	6	MOSI	SDA	11	NC	
Power Supply	+3.3V	7	3.3V	5V	10	+5V	Power Supply
Ground	GND	8	GND	GND	9	GND	Ground

RS232 Isolator click electrical specifications

Description	Min	Тур	Max	Unit
Receiver inputs	-30		+30	V
voltage range				

Onboard settings and indicators

Label Default Description Name nenr rooicnains ror all major microconfroile

Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.



ISO 27001: 2013 certification of informational security management system. ISO 14001: 2015 certification of environmental management system. OHSAS 18001: 2008 certification of occupational health and safety management system.



ISO 9001: 2015 certification of quality management system (QMS).



Time-saving embedded tools

MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918

Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com

LD1	PWR	1	Power LED indicator
J1	VCC SEL	Left	Power supply voltage
			selection: left position
			3V3, right position 5V
J2	J2	Soldered	CTS connection to
			mikroBUS™
J3	J3	Soldered	RTS connection
			to mikroBUS™
CN1	RS232	-	RS232 connector

Software Support

We provide a library for the RS232 Isolator Click as well as a demo application (example), developed using MIKROE <u>compilers</u>. The demo can run on all the main MIKROE <u>development boards</u>.

Package can be downloaded/installed directly from NECTO Studio Package Manager (recommended), downloaded from our <u>LibStock™</u> or found on <u>MIKROE github account</u>.

Library Description

This library contains API for RS232 Isolator Click driver.

Key functions

- Function settings RTS state.
- Read CTS state.
- Function for send command.

Example Description

This example reads and processes data from RS232 Isolator clicks.

The full application code, and ready to use projects can be installed directly from NECTO Studio Package Manager(recommended way), downloaded from our $\underline{\mathsf{LibStock}^{\mathsf{TM}}}$ or found on $\underline{\mathsf{MIKROE}}$ aithub account.


Other MIKROE Libraries used in the example:

- · MikroSDK.Board
- MikroSDK.Log
- Click.Rs232Isolator

Additional notes and informations

Depending on the development board you are using, you may need <u>USB UART click</u>, <u>USB UART 2 Click</u> or <u>RS232 Click</u> to connect to your PC, for development systems with no UART to USB interface available on the board. UART terminal is available in all MIKROE <u>compilers</u>.

Mikroe produces entire development toolchains for all major microcontroller architectures.





ISO 27001: 2013 certification of informational security management system.
ISO 14001: 2015 certification of environmental management system.
OHSAS 18001: 2008 certification of occupational health and safety management system.





MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918 Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com

mikroSDK

This Click board[™] is supported with $\underline{\mathsf{mikroSDK}}$ - MIKROE Software Development Kit. To ensure proper operation of mikroSDK compliant Click board[™] demo applications, mikroSDK should be downloaded from the $\underline{\mathsf{LibStock}}$ and installed for the compiler you are using.

www.mikroe.com

For more information about mikroSDK, visit the official page.

Resources

mikroBUS™

Click board™ Catalog

Click Boards™


Downloads

RS232 Isolator click schematic

ADM3252E datasheet

RS232 Isolator click 2D and 3D files

RS232 Isolator click example on Libstock







health and safety management system.